







































Original	Substituto
 Power	 Power
 Mute	 Mute / Dimmer
 DTV	 Shift + 1
 DTV	 TV/Radio /
 Radio	 Shift + TV/Radio / Program
 Radio	 Shift + 6
 USB	 Shift + 8
 DVD	 Shift + 2
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Substituto
 Tv Guide	 Guide / EPG / -/--
 0	 0
 Recall	 Back / Return
 Vol+	 Vol+
 P.Mode	 Picture / Format
 CH+	 CH+ / Page+
 S.Mode	 Sound / Title
 Vol-	 Vol-
 FAV	 Fav / Marker / PC
 CH-	 CH- / Page-
 Menu	 Menu / Home
 Up	 Up
 Exit	 Exit / Cancel / Clear
 Left	 Left
 OK	 OK
 Right	 Right
 Source	 AV / Input / RDS





Original	Substituto
	 Down
	 Info / Angle
	 Shift + Picture / Format
	 Sleep / Timer
	 Audio / Lang I/II
	 Subtitle / EQ
	 Text / Goto
	 Shift + Stop /
	 Zoom / Size
	 Display / Media
	 Shift + Power
	 D.Menu / Top
	 Rec / Rec Mode
	 I<< / Preset-
	 >>I / Preset+
	 Stop / Hold
	 Eject / Surround

Original	Substituto
	 Setup / OPT /
	 Smart / List
	 << / Tune-
	 >> / Tune+
	 Pause / Step / Freeze
	 Play / Slow
	 Shift + Text /
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Shift + Yellow / YouTube /
	 Yellow / YouTube / Repeat
	 Shift + Info / Angle
	 Blue / Prime Video / Random
	 Shift + Green / APP /

