






































































Original	Substituto	Original	Substituto
 Power	 Power	 TXT/MIX	 Text
 Sleep	 Sleep	 Play	 Play
 Mute	 Mute	 Pause	 Pause
 Mode	 Media	 Stop	 Stop
 1	 1	 Rec	 Rec
 2	 2	 >>/Index	 >>
 3	 3	 <</Hold	 <<
 4	 4	 I<<	 I<<
 5	 5	 >>I	 >>I
 6	 6	 Cancel	 Exit
 7	 7	 Menu	 Menu
 8	 8	 DTV/Radio	 TV/R
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 -/--	 Shift + Guide	 Up	 Up
 Back	 Back	 Down	 Down
 Nicam/A2	 Dual	 Right	 Right

Original	Substituto	Original	Substituto
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 PLAY	 PLAY	 PAUSE	 PAUSE
 STOP	 STOP	 STOP	 STOP
 RECORD	 RECORD	 RECORD	 RECORD
 INDEX	 INDEX	 INDEX	 INDEX
 HOLD	 HOLD	 HOLD	 HOLD
 SIZE	 SIZE	 SIZE	 SIZE
 REVEAL	 REVEAL	 REVEAL	 REVEAL
 CANCEL	 CANCEL	CLEAR EXIT	CLEAR EXIT
MENU	MENU	TOP MENU MENU	TOP MENU MENU
DTV/RADIO	DTV/RADIO	SEARCH TV/R	SEARCH TV/R
VOL+	VOL+	VOL+	VOL+
VOL-	VOL-	VOL-	VOL-
UP	UP	UP	UP
DOWN	DOWN	DOWN	DOWN
RIGHT	RIGHT	RIGHT	RIGHT



































Original	Substituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Original	Substituto
	















Original	Substituto	Original	Substituto
Power		Power	
Mute		Mute	
[ I ]/Menu		Menu	
Exit		Exit	
Source		AV	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Subtitle		Subt	
Text		Text	

Original	Substituto	Original	Substituto
Vol+		Vol +	
Vol-		Vol -	
CH+		Ch +	
CH-		Ch -	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK		Ok	
Recall		Back	
Info		Info	
EPG		Guide	
Freeze		Options	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	





Original	Substituto	Original	Substituto
Audio	 Dual		
I<</[≡+]	 I<<		
>>I/[≡..]	 >>I		
[≡i]	 Smart		
Play	 Play		
Pause	 Pause		
Stop	 Stop		
REP/Rec	 Rec		
<</[≡o]	 <<		
>>/[≡?]	 >>		
FAV	 Pre Ch		

