







































































Original		Substituto		Original		Substituto	
	Standby		Power		8		8
	Open / Close		Eject		9		9
	OSD		Blue		0		0
	Subtitle		Subt		10+		Guide
	Angle		Yellow		Goto		Pre Ch
	Language		Dual		Step		Ch +
	L / R		Red		Slow		Ch -
	N / P		Green		PBC		Media
	Video Mode		Format		Repeat		Text
	Video		AV		Program		Sleep
	1		1		A-B		Shift + Dual
	2		2		Vol +		Vol +
	3		3		Vol -		Vol -
	4		4		Setup		Options
	5		5		Setup		Menu
	6		6		Zoom		Shift + Eject
	7		7		Up		Up





Original	Substituto	Original	Substituto
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Title		TV/R
	Root		Info
	Return		Back
	Return		Exit
	3D		3D
	Mute		Mute
	Pause		Pause
	Play		Play
	Stop		Stop
	<< FR		<<
	>> FF		>>
	I<< Prev		I<<
	>>I Next		>>I

