



Original	Substituto	Original	Substituto
	Power		Power
	Netflix		Media
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV		TV/R
	Recall		Pre Ch
	V +		Vol +
	V -		Vol -
	Mute		Mute
	Home		Smart
	P +		Ch +
	P -		Ch -
	Menu		Menu
	Q.Menu		D. Menu
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Back		Back
	Exit		Exit
	i		Info
	Video		Shift + Smart
	EPG		Guide
	YouTube		Shift + Media



