







































































Original	Substituto	Original	Substituto
 Standby	 Power	 Up	 Up
 Mute	 Mute	 Down	 Down
 PN	 Smart	 Right	 Right
 Open/Close	 Eject	 Left	 Left
 <<	 <<	 OK	 Ok
 >>	 >>	 Vol+	 Vol +
 Play	 Play	 Vol-	 Vol -
 Pause	 Pause	 1	 1
 Stop	 Stop	 2	 2
 I<<	 I<<	 3	 3
 >>I	 >>I	 4	 4
 Setup	 Menu	 5	 5
 Source	 AV	 6	 6
 Info	 Info	 7	 7
 Return/Exit	 Back	 8	 8
 CH+	 Ch +	 9	 9
 CH-	 Ch -	 0	 0





Original	Substituto	Original	Substituto
Slow	Media		
Goto	Options		
Program	Sleep		
Title/TTX	Text		
Audio	Dual		
Subtitle	Subt		
Red/Repeat	Red		
Green/A-B	Green		
Yellow/Menu	Yellow		
Blue/Angle	Blue		
EPG	Guide		
Favorite	Pre Ch		
Tv/Radio	TV/R		
Record	Rec		