






































































Original	Substituto	Original	Substituto
 P100	 Guide / EPG / -/--	 AV	 AV / Input / RDS
 Power	 Power	 0	 0
 REV	 Sleep / Timer	 TV	 TV/Radio /
 DOUB	 Smart / List	 P+	 Up
 1	 1	 P+	 CH+ / Page+
 2	 2	 Mute	 Mute / Dimmer
 3	 3	 TV/TXT	 Text / Goto
 Hold	 Stop / Hold	 Menu	 Menu / Home
 4	 4	 Vol-	 Vol-
 5	 5	 Vol-	 Left
 6	 6	 OK	 OK
 SUB	 Subtitle / EQ	 Vol+	 Vol+
 Update	 Display / Media	 Vol+	 Right
 7	 7	 SWAP	 Back / Return
 8	 8	 P-	 CH- / Page-
 9	 9	 P-	 Down
 MIX	 D.Menu / Top	 16:9	 Picture / Format





Original

Substituto

	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Violet/Info		Info / Angle
	[]		Zoom / Size
	PC		Fav / Marker / PC
	PT		Setup / OPT /

Original

Substituto

