





































Original	Substituto
 Sleep	 Sleep / Timer
 Standby AV	 Shift + Power
 System Standby	 Power
 Video1	 Shift + 4
 Video 2	 Shift + 1
 DVD	 Shift + 2
 MD/Tape	 Shift + 5
 CD	 Shift + 3
 Tuner	 Shift + 6
 Top Menu	 Shift + D.Menu / Top Menu
 1 Tuner	 1
 Up	 Up
 2 Tuner	 2
 DVD Menu	 D.Menu / Top
 3 Tuner	 3
 Left	 Left
 4 Tuner	 4

Original	Substituto
 Enter	 OK
 5 Tuner	 5
 Right	 Right
 6 Tuner	 6
 7 Tuner	 7
 Down	 Down
 8 Tuner	 8
 Recall	 Fav / Marker / PC
 9 Tuner	 9
 >10 Tuner/Shift/-/-	 Guide / EPG / -/-
 0 Tuner	 0
 Enter/D.Tuning/Return Tuner	 Back / Return
 I<</CH/Preset-	 I<< / Preset-
 I<</CH Preset-Tuner	 Shift + I<< / Preset-
 >>I/CH/Preset+	 >>I / Preset+
 >>I/CH Preset+ Tuner	 Shift + >>I / Preset+
 Tv/Video/ANT	 AV / Input / RDS





Original	Substituto	Original	Substituto
 <<	 << / Tune-	 Master Vol+	 Vol+
 >>	 >> / Tune+	 Tv Vol+	 Shift + Vol+
 D.Skip/TV/VTR	 TV/Radio /	 Tv CH+	 Shift + CH+ /
 Play	 Play / Slow	 Master Vol-	 Vol-
 Pause	 Pause / Step / Freeze	 Tv Vol-	 Shift + Vol-
 Stop	 Stop / Hold	 Tv CH-	 Shift + CH- /
 2CH	 Sound / Title		
 A.F.D.	 Eject / Surround		
 Movie/Music	 Audio / Lang I/II		
 Test Tone	 Subtitle / EQ		
 Main Menu	 Menu / Home		
 Multi CH	 Picture / Format		
 < Menu	 Shift + Left		
 Menu >	 Shift + Right		
 Muting	 Mute / Dimmer		
 -	 CH- / Page-		
 +	 CH+ / Page+		

Original	Substituto	Original	Substituto
 Master Vol+	 Vol+	 Tv Vol+	 Shift + Vol+
 Tv Vol+	 Shift + Vol+	 Tv CH+	 Shift + Vol+
 Tv CH+	 Shift + Vol+	 Tv CH-	 Shift + CH- /
 Master Vol-	 Vol-		
 Tv Vol-	 Shift + Vol-		
 Tv CH-	 Shift + CH- /		







































Original	Substituto
 Standby	 Power
 Video 1	 Shift + 4
 Video 2	 Shift + 1
 DVD	 Shift + 2
 MD/Tape	 Shift + 5
 CD	 Shift + 3
 Tuner	 Shift + 6
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 >10/Shift/-/-	 Guide / EPG / -/-

Original	Substituto
 0	 0
 Enter/D.Tuning/Return	 Back / Return
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 D.Skip/TV/VTR	 TV/Radio /
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Muting	 Mute / Dimmer
 Master Vol+	 Vol+
 Master Vol-	 Vol-





Original	Substituto
 Standby CD	 Power
 Standby Video	 Shift + Power
 Video 1	 Smart / List
 Video 2	 Display / Media
 DVD	 Blue / Prime Video / Random
 MD/Tape	 Green / APP / Repeat
 CD	 Yellow / YouTube / Repeat
 Tuner	 Red / Netflix / Search
 1 CD	 1
 1 Video 1	 Shift + 1
 2 CD	 2
 2 Video 1	 Shift + 2
 3 CD	 3
 3 Video 1	 Shift + 3
 4 CD	 4
 4 Video 1	 Shift + 4
 5 CD	 5

Original	Substituto
 5 Video 1	 Shift + 5
 6 CD	 6
 6 Video 1	 Shift + 6
 7 CD	 7
 7 Video 1	 Shift + 7
 8 CD	 8
 8 Video 1	 Shift + 8
 9 CD	 9
 9 Video 1	 Shift + 9
 >10/Shift/-/ CD	 Guide / EPG / -/ -
 >10/Shift/-/ Video 1	 Shift + Guide / EPG / -/ -
 0 CD	 0
 0 Video 1	 Shift + 0
 Enter/D.Tuning/Return CD	 Back / Return
 Enter/D.Tuning/Return Video 1	 Shift + Back / Return
 I<< CD	 I<< / Preset-
 I<< Video 1	 Shift + I<< / Preset-





Original	Substituto
Standby	Power
Standby Video	+ Shift + Power
Video 1	Smart / List
Video 2	Display / Media
DVD	Blue / Prime Video / Random
MD/Tape	Green / APP / Repeat
CD	Yellow / YouTube / Repeat
Tuner	Red / Netflix / Search
1 MD/Tape	1
1 Video 2	+ Shift + 1
2 MD/Tape	2
2 Video 2	+ Shift + 2
3 MD/Tape	3
3 Video 2	+ Shift + 3
4 MD/Tape	4
4 Video 2	+ Shift + 4
5 MD/Tape	5

Original	Substituto
5 Video 2	+ Shift + 5
6 MD/Tape	6
6 Video 2	+ Shift + 6
7 MD/Tape	7
7 Video 2	+ Shift + 7
8 MD/Tape	8
8 Video 2	+ Shift + 8
9 MD/Tape	9
9 Video 2	+ Shift + 9
>10/Shift/-/- MD/Tape	Guide / EPG / -/-
>10/Shift/-/- Video 2	+ Shift + Guide / EPG / -/-
0 MD/Tape	0
0 Video 2	+ Shift + 0
Enter/D.Tuning/Return MD/Tape	Back / Return
Enter/D.Tuning/Return Video 2	+ Shift + Back / Return
I<< MD/Tape	I<< / Preset-
I<< Video 2	+ Shift + I<< / Preset-





Original	Substituto	Original	Substituto
 >>I MD/Tape	 >>I / Preset+		
 >>I Video 2	 +  Shift + >>I / Preset+		
 << MD/Tape	 << / Tune-		
 << Video 2	 +  Shift + << /		
 >> MD/Tape	 >> / Tune+		
 >> Video 2	 +  Shift + >> /		
 D.Skip/TV/VTR MD/Tape	 AV / Input / RDS		
 D.Skip/TV/VTR Video 2	 +  Shift + AV / Input / RDS		
 Play MD/Tape	 Play / Slow		
 Play Video 2	 +  Shift + Play /		
 Pause MD/Tape	 Pause / Step / Freeze		
 Pause Video 2	 +  Shift + Pause / Step /		
 Stop MD/Tape	 Stop / Hold		
 Stop Video 2	 +  Shift + Stop /		
 Muting	 Mute / Dimmer		
 Master Vol+	 Vol+		
 Master Vol-	 Vol-		

Original	Substituto

