







































































Original	Substituto	Original	Substituto
 Power	 Power	 +10	 Guide
 Quick OSD	 Media	 Cancel	 Exit
 FL Select	 Smart	 Play Speed	 Red
 Open/Close	 Eject	 Dialogue	 Green
 Advanced	 TV/R	 Manual Skip	 Yellow
 Picture Mode	 Format	 Quick Replay	 List
 Repeat	 Text	 I<< Skip	 I<<
 1	 1	 Skip >>I	 >>I
 2	 2	 << Slow/Search	 <<
 3	 3	 Slow/Search >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause	 Pause
 6	 6	 Play	 Play
 7	 7	 Top Menu	 Shift + Menu
 8	 8	 Menu	 Menu
 9	 9	 Functions	 D. Menu
 0	 0	 Return	 Back



