





































































Original	Substituto	Original	Substituto
 Open / Close	 Eject / Surround	 8	 8
 Power	 Power	 9	 9
 V.Mode	 Picture / Format	 OSD	 Display / Media
 Title	 Sound / Title	 N/P	 Red / Netflix / Search
 Subtitle	 Subtitle / EQ	 0	 0
 Menu	 Menu / Home	 Setup	 Setup / OPT /
 Repeat	 Green / APP / Repeat	 Up	 Up
 A-B RPT	 Yellow / YouTube / Repeat	 Intro	 OK
 Angle	 Info / Angle	 Left	 Left
 Audio	 Audio / Lang I/II	 Play	 Play / Slow
 1	 1	 Right	 Right
 2	 2	 Zoom	 Zoom / Size
 3	 3	 Down	 Down
 4	 4	 Prog	 TV/Radio /
 5	 5	 CH+	 CH+ / Page+
 6	 6	 Rec	 Rec / Rec Mode
 7	 7	 CH-	 CH- / Page-





Original	Substituto	Original	Substituto
 Timer	 Sleep / Timer	 Edit	 Text / Goto
 Quality	 Blue / Prime Video / Random	 Chap Mark	 Smart / List
 Disc	 D.Menu / Top		
 <<	 << / Tune-		
 >>	 >> / Tune+		
 I<<	 I<< / Preset-		
 >>I	 >>I / Preset+		
 Pause / Step	 Pause / Step / Freeze		
 Stop	 Stop / Hold		
 <I Slow	 Shift + Left		
 Slow I>	 Shift + Right		
 DVD	 Shift + 2		
 Mute	 Mute / Dimmer		
 Volume-	 Vol-		
 Volume+	 Vol+		
 Source	 AV / Input / RDS		
 Book Mark	 Fav / Marker / PC		

