







































































Original	Substituto	Original	Substituto
 Standby	 Power	 0	 0
 Open/Close	 Eject / Surround	 Title	 Sound / Title
 Audio	 Audio / Lang I/II	 Up	 Up
 1	 1	 Menu	 Menu / Home
 2	 2	 Left	 Left
 3	 3	 OK	 OK
 Angle	 Info / Angle	 Right	 Right
 4	 4	 Display	 Display / Media
 5	 5	 Down	 Down
 6	 6	 Video Out	 AV / Input / RDS
 Subtitle	 Subtitle / EQ	 Return	 Back / Return
 7	 7	 Setup	 Setup / OPT /
 8	 8	 Mode	 D.Menu / Top
 9	 9	 Vol+	 Vol+
 Search	 Red / Netflix / Search	 Mute	 Mute / Dimmer
 PRG	 TV/Radio /	 Mark	 Fav / Marker / PC
 CLR	 Exit / Cancel / Clear	 Zoom	 Zoom / Size





Original	Substituto	Original	Substituto
	Vol-		
	Yellow / YouTube / Repeat		
	CH- / Page-		
	CH+ / Page+		
	<< / Tune-		
	>> / Tune+		
	I<< / Preset-		
	>>I / Preset+		
	Stop / Hold		
	Pause / Step / Freeze		
	Play / Slow		

