







































































Original		Substituto		Original		Substituto	
	View DVD		Smart		Timer		Shift + AV
	View VCR		Media		F.ADV / Step		Pre Ch
	TV / VCR		TV/R		I<<		I<<
	Input SEL.		AV		Rec		Rec
	Standby / On		Power		Speed		Sleep
	Open / Close		Eject		>>I		>>I
	Info		Info		<<		<<
	1		1		Stop		Stop
	2		2		Play		Play
	3		3		Pause		Pause
	4		4		>>		>>
	5		5		TRK +		Vol +
	6		6		TRK -		Vol -
	7		7		Audio		Dual
	8		8		Prog +		Ch +
	9		9		Prog -		Ch -
	0		0		Menu		Menu





Original	Substituto
Return	Back
Up	Up
Right	Right
Down	Down
Left	Left
OK	Ok
Disc Menu	D. Menu
Clear	Exit
Zoom	+ Shift + Eject
EZ View	Options
Subtitle	Subt
Angle / IPC	Format
Mode / Repeat	Text
Mark / Search	+ Shift + TV/R

Original	Substituto

