







Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	PIP		Smart / List
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	Mute		Mute / Dimmer
	i		Info / Angle
	Z		Menu / Home

Original	Substituto	Original	Substituto
	P+		CH+ / Page+
	P+		Up
	-		Left
	-		Vol-
	OK		OK
	+		Right
	+		Vol+
	TXT		Text / Goto
	P-		CH- / Page-
	P-		Down
	AV		AV / Input / RDS
	Scan/[]		Setup / OPT /
	PAP/Pause		Display / Media
	Size/Stop		Zoom / Size
	Pos/Play		D.Menu / Top
	Red/I<		Red / Netflix / Search
	Green/>I		Green / APP / Repeat






































Original	Substituto
 Yellow/Pause/<	 Yellow / YouTube / Repeat
 Blue/>>	 Blue / Prime Video / Random

Original	Substituto







Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	PIP		Smart / List
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	i		Info / Angle
	Z		Menu / Home
	P+		CH+ / Page+

Original	Substituto	Original	Substituto
	P+		Up
	-		Left
	-		Vol-
	OK		OK
	+		Right
	+		Vol+
	TXT		Text / Goto
	P-		CH- / Page-
	P-		Down
	AV		AV / Input / RDS
	Scan/[']		Setup / OPT /
	PAP/PAUSE		Pause / Step / Freeze
	SIZE/STOP		Stop / Hold
	Pos/PLAY		Play / Slow
	Red/ <		<< / Preset-
	Green/>		>> / Preset+
	Yellow/PAUSE/<		<< / Tune-









































Original	Substituto
 Blue/>>	 >> / Tune+

Original	Substituto





Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	PIP		Smart / List
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	7		7
	8		8
	9		9
	-/-		Guide / EPG / -/-
	0		0
	Mute		Mute / Dimmer
	i		Info / Angle
	Z		Menu / Home

Original	Substituto	Original	Substituto
	P+		CH+ / Page+
	P+		Up
	-		Left
	-		Vol-
	OK		OK
	+		Vol+
	+		Right
	TXT		Text / Goto
	P-		CH- / Page-
	P-		Down
	AV		AV / Input / RDS
	Scan/[]		Setup / OPT /
	PAP/Pause		Pause / Step / Freeze
	Size/Stop		Stop / Hold
	Pos/Play		Play / Slow
	Red/I<		I<< / Preset-
	Green/>I		>>I / Preset+

































































Original	Substituto	Original	Substituto
Yellow/Left Arrow	TUNE- (Left Arrow)		
Blue/Right Arrow	TUNE+ (Right Arrow)		





Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	PIP		Smart / List
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	7		7
	8		8
	9		9
	-/-		Guide / EPG / -/-
	0		0
	i		Info / Angle
	Z		Menu / Home
	P+		CH+ / Page+

Original	Substituto	Original	Substituto
	P+		Up
	-		Vol-
	-		Left
	OK		OK
	+		Vol+
	+		Right
	TXT		Text / Goto
	P-		CH- / Page-
	P-		Down
	AV		AV / Input / RDS
	Scan/[']		Setup / OPT /
	PAP/Pause		Pause / Step / Freeze
	Size/Stop		Stop / Hold
	Pos/Play		Play / Slow
	Red/ <		<< / Preset-
	Green/>		>> / Preset+
	Yellow/Pause/<		<< / Tune-





Original	Substituto
	>> / Tune+

Original	Substituto

