



































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV/Radio		TV/R
	←PR		Back
	FAV		Pre Ch
	Menu		Menu
	SAT		Smart

Original	Substituto	Original	Substituto
	Info		Info
	Page Up		>>I
	Page Down		I<<
	Up / PR+		Up
	Up / PR+		Ch +
	Down / PR-		Down
	Down / PR-		Ch -
	Right / Vol+ / W		Right
	Left / Vol- / E		Left
	Right / Vol+ / W		Vol +
	Left / Vol- / E		Vol -
	OK / List		Ok
	OK / List		List
	Exit		Exit
	EPG		Guide
	TV/AV		AV
	Pause		Shift + Pause





Original		Substituto		Original		Substituto	
	PAL/NTSC		Format				
	UHF		Media				
	Red / Audio		Red				
	Red / Audio		Dual				
	Green / Position		Green				
	Yellow / Subtitle		Yellow				
	Yellow / Subtitle		Subt				
	Blue / L/R		Blue				
	REW		<<				
	Play / Slow		Play				
	Stop		Stop				
	F.F		>>				
	Pause (For PVR)		Pause				
	Rec		Rec				

