












Original		Substituto		Original		Substituto	
	Function		Power		Right		Right
	Language		Dual		Left		Left
	Screen On/Off		Smart		OK		Ok
	Setup		Options		Play		Play
	Vol+		Vol +		Pause		Pause
	Vol-		Vol -		1		1
	Mute		Mute		2		2
	Info/Display		Info		3		3
	Stop/USB/Card		Stop		4		4
	DVD Menu		D. Menu		5		5
	Title		List		6		6
	Tv/Radio		TV/R		7		7
	TTX		Text		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		EPG/Program/Angl		Guide
	Down		Down		Zoom/Slow		3D



