







































































Original	Substituto	Original	Substituto
 Power	 Power	 Display	 Info
 VCR/DVD	 Media	 On Screen/Progressiv	 3D
 DVD Timer	 Green	 Top	 Shift + Menu
 VCR Timer	 Red	 Menu	 Menu
 1	 1	 Set Up	 Options
 2	 2	 Return	 Back
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 I<</Previous	 I<<
 9	 9	 >>I/Next	 >>I
 0/AUX	 0	 <</Slow-	 <<
 X/Cancel	 Exit	 Play/Select	 Play
 Showview/Video Plus+	 Guide	 >>/Slow+	 >>
 Prog/Check	 Sleep	 Stop/Clear	 Stop

Original	Substituto	Original	Substituto
 Power	 Power	 Display	 Info
 VCR/DVD	 Media	 On Screen/Progressiv	 3D
 DVD Timer	 Green	 Top	 Shift + Menu
 VCR Timer	 Red	 Menu	 Menu
 1	 1	 Set Up	 Options
 2	 2	 Return	 Back
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 I<</Previous	 I<<
 9	 9	 >>I/Next	 >>I
 0/AUX	 0	 <</Slow-	 <<
 X/Cancel	 Exit	 Play/Select	 Play
 Showview/Video Plus+	 Guide	 >>/Slow+	 >>
 Prog/Check	 Sleep	 Stop/Clear	 Stop





Original	Substituto	Original	Substituto
Power	Power	Prog/Check	Sleep
VCR/DVD	Media	Display	Info
DVD Timer	Green	On Screen/Progressiv	3D
VCR Timer	Red	Top	Shift + Menu
1	1	Menu	Menu
2	2	Set Up	Options
3	3	Return	Back
4	4	Up	Up
5	5	Down	Down
6	6	Right	Right
7	7	Left	Left
8	8	Enter	Ok
9	9	I<</Previous	I<<
0/AUX	0	>>/Next	>>I
X/Cancel	Exit	<</Slow-	<<
Memory/Mark	Smart	Play Select	Play
Showview/Video Plus+	Guide	>>/Slow+	>>

Original	Substituto	Original	Substituto
Power	Power	Prog/Check	Sleep
VCR/DVD	Media	Display	Info
DVD Timer	Green	On Screen/Progressiv	3D
VCR Timer	Red	Top	Shift + Menu
1	1	Menu	Menu
2	2	Set Up	Options
3	3	Return	Back
4	4	Up	Up
5	5	Down	Down
6	6	Right	Right
7	7	Left	Left
8	8	Enter	Ok
9	9	I<</Previous	I<<
0/AUX	0	>>/Next	>>I
X/Cancel	Exit	<</Slow-	<<
Memory/Mark	Smart	Play Select	Play
Showview/Video Plus+	Guide	>>/Slow+	>>





Original	Substituto	Original	Substituto
Stop/Clear	Stop		
Pause	Pause		
Rec	Rec		
Remain/Rec	Shift + Rec		
↔	Pre Ch		
→	Blue		
Angle/Live Check	AV		
Subtitle	Subt		
TV/DVD-TV/VCR	TV/R		
Mute/Audio	Mute		
PR+	Ch +		
PR- TV/CBL/DVD	Ch -		
Vol+ Tv	Vol +		
Vol- Tv	Vol -		





Original	Substituto	Original	Substituto
Power	Power	Menu	Menu
VCR/DVD	Media	Up	Up
DVD Timer	Green	Down	Down
VCR Timer	Red	Right	Right
1	1	Left	Left
2	2	Enter	Ok
3	3	I<</Previous	I<<
4	4	>>/Next	>>I
5	5	<</Slow-	<<
6	6	Play/Select	Play
7	7	>>/Slow+	>>
8	8	Stop/Clear	Stop
9	9	Pause	Pause
0/AUX	0	Rec	Rec
Prog/Check	Sleep	Remain/Rec	Shift + Rec
Display	Info	↔	Pre Ch
Top	Shift + Menu	→	Blue



