





























































Original	Substituto	Original	Substituto
 Power	 Power	 TV/AV	 AV / Input / RDS
 Open/Close	 Eject / Surround	 P+	 CH+ / Page+
 Scan	 Display / Media	 TV/DVD	 Smart / List
 Swap	 Back / Return	 V-	 Vol-
 Call	 Shift + OK	 Menu	 Menu / Home
 Mute	 Mute / Dimmer	 V+	 Vol+
 1	 1	 Exit	 Exit / Cancel / Clear
 2	 2	 P-	 CH- / Page-
 3	 3	 P.STD	 Picture / Format
 4	 4	 Red/Picture	 Shift + Picture / Format
 5	 5	 Red/Picture	 Red / Netflix / Search
 6	 6	 Green/Sound	 Sound / Title
 7	 7	 Green/Sound	 Green / APP / Repeat
 8	 8	 Yellow/Time	 Yellow / YouTube / Repeat
 9	 9	 Blue/Function	 Blue / Prime Video / Random
 0	 0	 <<	 << / Tune-
 -/--	 Guide / EPG / -/--	 >>	 >> / Tune+





Original	Substituto
 <<	 << / Preset-
 >>	 >> / Preset+
 Tune	 +  Shift + TV/Radio / Program
 Up	 Up
 Down	 Down
 Program	 TV/Radio /
 Zoom	 Zoom / Size
 D.Call	 Info / Angle
 [◆]	 +  Shift + Zoom /
 [-]	 D.Menu / Top
 [/ =]	 +  Shift + Text /
 [=]	 Text / Goto
 [X]	 +  Shift + Exit / Cancel / Clear
 [?]	 Setup / OPT /
 [+]	 Subtitle / EQ
 Timer	 Sleep / Timer
 >	 Right

Original	Substituto







































Original	Substituto	Original	Substituto
 Power	 Power	 TV/AV	 AV / Input / RDS
 Open / Close	 Eject / Surround	 I-II	 Shift + Audio / Lang I/II
 Scan	 Shift + Setup / OPT / Tools	 P+	 CH+ / Page+
 Swap	 Back / Return	 TV/DVD	 Shift + 2
 Call	 Smart / List	 TV/DVD	 Shift + 1
 Mute	 Mute / Dimmer	 V-	 Vol-
 1	 1	 Menu	 Menu / Home
 2	 2	 V+	 Vol+
 3	 3	 Exit	 Exit / Cancel / Clear
 4	 4	 P-	 CH- / Page-
 5	 5	 P.Std	 Picture / Format
 6	 6	 Red / Picture	 Red / Netflix / Search
 7	 7	 Red / Picture	 Shift + Picture / Format
 8	 8	 Green / Sound	 Green / APP / Repeat
 9	 9	 Green / Sound	 Shift + Sound / Title
 0	 0	 Yellow / Time	 Yellow / YouTube / Repeat
 -/--	 Guide / EPG / -/--	 Yellow / Time	 Sleep / Timer





Original	Substituto
 Blue / Function	 Blue / Prime Video / Random
 Rev	 << / Tune-
 Fwd	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Stop	 Stop / Hold
 Setup	 Setup / OPT /
 Pause / Step	 Pause / Step / Freeze
 White / Tune	 Display / Media
 D.Menu	 D.Menu / Top
 Up	 Up
 Repeat	 Shift + Green / APP /
 A-B	 Shift + Yellow / YouTube /
 Left	 Left
 Play / Enter	 Play / Slow
 Play / Enter	 OK
 Right	 Right

Original	Substituto
 Slow	 Shift + Play /
 Angle	 Info / Angle
 Down	 Down
 Title / PBC	 Sound / Title
 Search	 Shift + Red / Netflix /
 Audio	 Audio / Lang I/II
 Program	 TV/Radio /
 Zoom	 Zoom / Size
 D.Call	 Shift + Smart / List
 10+	 Shift + Guide / EPG / -/-
 Caption	 Subtitle / EQ
 Hold	 Shift + Stop /
 [-]	 Shift + TV/Radio / Program
 Mix	 Shift + Text /
 Text	 Text / Goto
 [X]	 Shift + Exit / Cancel / Clear
 Reveal	 Shift + Sleep / Timer





Original

Substituto

	Size		+		Shift + Zoom /
	Subcode		+		Shift + Subtitle / EQ
	>		+		Shift + Eject / Surround

Original

Substituto

