








































































Original	Substituto	Original	Substituto
	Power		Power
	SD Card		List
	Tv Input		TV/R
	AV Input		AV
	Menu		Menu
	[+]/Aspect		3D
	Internet		Smart
	Direct Tv Rec		Shift + TV/R
	i		Info
	Exit		Exit
	Viera Link		D. Menu
	Viera Tools		Media
	Option		Options
	Guide		Guide
	Return/Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡]/Text		Text
	[≡◆]/STTL		Subt
	[≡i]/Index		Dual
	[≡+]/Hold		Format
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6





Original	Substituto	Original	Substituto
 7	7	 7	7
 8	8	 8	8
 9	9	 9	9
 0	0	 0	0
 Last View	 Pre Ch		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		
 CH+	 Ch +		
 CH-	 Ch -		
 Power Down Tv	 Shift + Power		
 Stop Tv	 Stop		
 Play Tv	 Play		
 Pause/Step Tv	 Pause		
 >>/>>I Tv	 >>I		
 <</I<< TV	 I<<		
 Rec TV	 Rec		

Original	Substituto	Original	Substituto
 Programme Up	 Shift + Ch +		
 Programme Down	 Shift + Ch -		
 Power DVD/VCR	 Shift + Ok		
 Rec DVD/VCR	 Shift + Rec		
 <</I<<	 Shift + I<<		
 >/>>I DVD/VCR	 Shift + >>I		
 Play DVD/VCR	 Shift + Play		
 Pause/Step	 Shift + Pause		
 Stop DVD/VCR	 Shift + Stop		
 Programme Up DVD/VCR	 Shift + Up		
 Programme Down DVD/VCR	 Shift + Down		

