







































































Original	Substituto	Original	Substituto
	Power		Power
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	>>		>>
	Left		Left
	<<		<<
	Back		Back
	Options		Options
	Disc		Menu
	Open/Close		Eject
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Stop		Stop
	>		>>
	Play/Pause		Play
	<		<<
	Home		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Sound		Dual
	Surr		Subt
	Source/Audio		AV
	Radio		TV/R



