



































Original	Substituto	Original	Substituto
PWR On/Off	 Power	Volume+	 Vol +
Mute	 Mute	CH/Page+	 Ch +
Subt.List	 Subt	Volume-	 Vol -
Sleep Timer	 Sleep	App	 Media
TV	 TV/R	CH/Page-	 Ch -
Video	 D. Menu	1. ?	 1
Text	 Text	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7
OK Enter	 Ok	8tuv	 8
Menu Right	 Right	9wxyz	 9
Exit	 Exit	Epg	 Guide
Menu Down	 Down	0/10	 0
Back	 Back	Red	 Red



Original	Substituto	Original	Substituto
Green	 Green		
Yellow	 Yellow		
Blue	 Blue		
Info	 +  =  Shift + Info		
East	 +  = Shift + Red		

