







































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	DTV / ATV		D.Menu / Top
	0		0
	Recall		Back / Return
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	Sleep		Sleep / Timer
	Vol +		Vol+
	MTS		Audio / Lang I/II
	CH +		CH+ / Page+
	Vol -		Vol-
	REC List		Smart / List
	CH -		CH- / Page-
	FAV List		Fav / Marker / PC
	REC		Rec / Rec Mode
	Freeze		Pause / Step / Freeze
	Menu		Menu / Home
	Up		Up
	Source		AV / Input / RDS
	Left		Left
	Enter		OK
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down





Original	Substituto
Display	Display / Media
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
<< / Guide	<< / Tune-
<< / Guide	Guide / EPG / -/--
Play/Pause / Timeshift	Play / Slow
>> / Aspect	>> / Tune+
<< / Cancel	<< / Preset-
>> / Subpage	>> / Preset+
Stop / Index	Info / Angle
Stop / Index	Stop / Hold
TV / Radio	TV/Radio /
Subtitle	Subtitle / EQ
Reveal	Setup / OPT /
Size	Zoom / Size

Original	Substituto
Hold	Shift + Stop /
Text	Text / Goto

