Original		Substituto	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Recall	FAV PRE-CH	Pre Ch
	Input	TIMER AV	AV
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
P	P+	+ CH	Ch +

Original		Substituto	
P	P-	CH −	Ch -
CONTENT MENU	Content Menu	HOME SMART	Smart
DVD MENU MENU	Menu/DVD	TOP MENU MENU	Menu
RETURN EXIT	Exit/Return	CLEAR EXIT	Exit
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
SET UP	Setup	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	[<>]	PICTURE FORMAT	Format
	⇥I/I←	ECO 3D	3D

Original		Substituto		Original		Substituto	
	[i +] / [≡i]	DISPLAY INFO	Info				
AUDIO TEXT	Text / Audio	REPEAT TEXT	Text				
SUBTITLE	Subtitle	AD SUBT	Subt				
CD I/II	Stop/ O) I / I I		Stop				
SUBTITLE	Open/ Close	ZOOM	Eject				
	Play/ [≡o]	PLAY MODE	Play				
	Pause/ Step/ [▼]		Pause				
	I <</ [≡?]		I <<				
	<</ [≡+]		<<				
	>>/ [♦]		>>				
	>>I / [O] / [≡x]		>>I				

Original		Substituto	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Input	TIMER AV	AV
+ VOL	Vol +	+ VOL	Vol +
− VOL	Vol -	− VOL	Vol -
	Mute	MUTE	Mute
DVD MENU MENU	Menu/DVD	TOP MENU MENU	Menu
RETURN EXIT	Exit/Return	CLEAR EXIT	Exit

Original		Substituto	
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
SET UP	Set Up	SETTINGS OPT	Options
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
	[<>]	PICTURE FORMAT	Format
	⇥I / I←	ECO 3D	3D
	[i+] / [≡i]	DISPLAY INFO	Info
AUDIO TEXT	Text/Audio	REPEAT TEXT	Text
SUBTITLE	Subtitle	AD SUBT	Subt
SUBTITLE	Open/Close	ZOOM ⏏	Eject
CD I/II ■	Stop/O)I/II	■	Stop
	Play/[≡o]	PLAY MODE ▶	Play
II/II▶	Pause/Step/[▼]	II	Pause
	I<</[≡?]	I<<	I<<

Original		Substituto		Original		Substituto	
	<</ [≡+]		<<				
	>>/ [♦]		>>				
	>>I / [O] / [≡x]		>>I				

Original		Substituto	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Recall	FAV PRE-CH	Pre Ch
	Input	TIMER AV	AV
CONTENT MENU	Content Menu	HOME SMART	Smart
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute

Original		Substituto	
P	P+	CH +	Ch +
P	P-	CH −	Ch -
DVD MENU MENU	Menu/DVD	TOP MENU MENU	Menu
RETURN EXIT	Exit/Return	CLEAR EXIT	Exit
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
SET UP	Set Up	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	[<>]	PICTURE FORMAT	Format
	⇥I / I←	ECO 3D	3D

Original		Substituto		Original		Substituto	
	[i +] / [≡i]	DISPLAY INFO	Info				
AUDIO TEXT	Text / Audio	REPEAT TEXT	Text				
SUBTITLE	Subtitle	AD SUBT	Subt				
SUBTITLE	Open/ Close	ZOOM	Eject				
CD I/II	Stop/ O) I / I I		Stop				
	Play/ [≡o]	PLAY MODE	Play				
II/II▶	Pause/ Step/ [▼]		Pause				
	I <</ [≡?]		I <<				
	</ [≡+]		<<				
	>>/ [♦]		>>				
CD/DX	>>I / [O] / [≡x]		>>I				