Mandis shop

Philips 996510068679

Original		Substituto	
	Power		Power
HDMI ARC	HDMI / ARC	TIMER AV	AV
Bluetooth	Bluetooth	TOP MENU MENU	Menu
COAX	Coaxial	DISPLAY INFO	Info
OPTICAL	Optical	SETTINGS OPT	Options
AUDIO IN	Audio In	SOUND DUAL	Dual
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
ON SURR SOUND	Surr. Sound On	HOME SMART	Smart
SURR SOUND OFF	Surr. Sound Of	APP MEDIA	Media
TREBLE +	Treble+		Up
TREBLE -	Treble-		Down
BASS +	Bass+		Right
BASS -	Bass-		Left
AUDIO SYNC +	Audio Sync+	CH +	Ch +
AUDIO SYNC -	Audio Sync-	CH -	Ch -

Original		Substituto	
RESET	♪/ Reset	CLEAR EXIT	Exit