Mandis shop

Sony RM-DX50

Original		Substituto	
CONTINUE	Continue	LIST SMART	Smart / List
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
>10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
10	10	HDMI - SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CHECK	Check	RETURN BACK	Back / Return
TIME	Time	TIMER SLEEP	Sleep / Timer

Original		Substituto	
DISPLAY ON/OFF	Display On/Off	MEDIA DISPLAY	Display / Media
REPEAT CLEAR	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
FADER	Fader	DIMMER MUTE	Mute / Dimmer
▷	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
AMS ⏮	I<<	PRESET- ⏮	I<< / Preset-
AMS ⏭	>>I	PRESET+ ⏭	>>I / Preset+
LINE OUT LEVEL	Line Out Level+	CH PAGE +	CH+ / Page+
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
	Line Out Level-	CH PAGE −	CH- / Page-

https://controleremoto.pt/pt/Sony/1068581-6276-comando-de-substituicao-para-Sony-RMDX50-147372012.html