Mandis shop

RC-794

Original		Substituto	
power	Power	power	Power
sleep	Sleep	TIMER SLEEP	Sleep / Timer
display	Display	MEDIA DISPLAY	Display / Media
muting	Muting	DIMMER MUTE	Mute / Dimmer
FM/AM	FM/AM	SHIFT + TUNER 6	Shift + 6
tape	Tape	SHIFT + TAPE 5	Shift + 5
aux	AUX	SHIFT + AUX - HDD 7	Shift + 7
BBS	BBS	APP REPEAT	Green / APP / Repeat
EEPS	EEPS	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
volume up	Vol+	+ VOL	Vol+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7

Original		Substituto	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
down	Vol-	VOL −	Vol-
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
tuning mode/ check	Tuning	SIZE ZOOM	Zoom / Size
shuffle RDS	Shuffle/RDS	RDS AV INPUT	AV / Input / RDS
repeat mono	Repeat/Mono	GOTO TEXT	Text / Goto
program	Program	PROGRAM TV/ RADIO	TV/Radio /
tuning/	I<</Tuning-Preset Down	PRESET-	I<< / Preset-
preset	>>I/Tuning-Preset Up	PRESET+	>>I / Preset+
	< Tape		Left
	> Tape		Right
►/II	Play/Pause CD	SLOW	Play / Slow
record	Record Tape	REC MODE	Rec / Rec Mode
	Stop Tape	OK	OK
clear	Stop/Clear CD	HOLD	Stop / Hold

https://controleremoto.pt/pt/Teac/1068847-97100-comando-de-substituicao-para-Teac-RC-794.html