


| Original | | Substituto | |
|---|---|---|---|
| Power | | Power | |
| Open / Close | | Eject / Surround | |
| Language | | Audio / Lang I/II | |
| Angle | | Info / Angle | |
| Subtitle | | Subtitle / EQ | |
| Time | | Sleep / Timer | |
| Display | | Display / Media | |
| PDVD | | Smart / List | |
| 1 | | 1 | |
| 2 | | 2 | |
| 3 | | 3 | |
| 4 | | 4 | |
| 5 | | 5 | |
| 6 | | 6 | |
| 7 | | 7 | |
| 8 | | 8 | |
| 9 | | 9 | |

| Original | | Substituto | |
|---|---|---|---|
| 0/10 | | 0 | |
| 10+ | | Guide / EPG / -/-- | |
| Prog | | TV/Radio / | |
| Mute | | Mute / Dimmer | |
| Zoom | | Zoom / Size | |
| A-B | | Yellow / YouTube / Repeat | |
| Repeat | | Green / APP / Repeat | |
| Step | | Shift + Pause / Step / | |
| Slow | | Shift + Play / | |
| Return | | Back / Return | |
| Resume | | Fav / Marker / PC | |
| View | | AV / Input / RDS | |
| Ran | | Blue / Prime Video / Random | |
| Vol- | | Vol- | |
| Vol+ | | Vol+ | |
| Menu | | Menu / Home | |
| Up | | Up | |






| Original | | Substituto | | Original | | Substituto | |
|---|---|---|---|---|---|---|---|
| TITLE | Title | TITLE SOUND | Sound / Title | | | | |
| | Left | | Left | | | | |
| ENTER | Enter | OK | OK | | | | |
| | Right | | Right | | | | |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / | | | | |
| | Down | | Down | | | | |
| PBC | PBC | GOTO TEXT | Text / Goto | | | | |
| REV | Rev | TUNE- | << / Tune- | | | | |
| FWD | Fwd | TUNE+ | >> / Tune+ | | | | |
| PREV | Prev | PRESET- | I<< / Preset- | | | | |
| NEXT | Next | PRESET+ | >>I / Preset+ | | | | |
| L/R | L/R | TOP MENU D.MENU | D.Menu / Top | | | | |
| N/P | N/P | FORMAT PICTURE | Picture / Format | | | | |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | | | |
| PLAY | Play | SLOW | Play / Slow | | | | |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze | | | | |
| STOP | Stop | HOLD | Stop / Hold | | | | |

