Mandis shop

LG AKB74935640



Original		Substituto	
	Power		Power
F	F	SMART	Smart / List
BASS BLAST ON / OFF	Bass Blast On/Off	AUDIO	Audio / Lang I/II
VOL +	Vol+	VOL +	Vol+
DRC ON	DRC On	NETFLIX SEARCH	Red / Netflix / Search
	Mute	DIMMER MUTE	Mute / Dimmer
VOL –	Vol-	VOL –	Vol-
DRC OFF	DRC Off	APP REPEAT	Green / APP / Repeat
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
REAR LEVEL +	Rear Level+	TV 1	1
WOOFER LEVEL +	Woofer Level+	DVD 2	2
AUTO POWER ON	Auto Power On	CD - STB 3	3
REAR LEVEL –	Rear Level-	VIDEO 4	4
WOOFER LEVEL –	Woofer Level-	TAPE 5	5

Original		Substituto	
AUTO POWER OFF	Auto Power Off	TUNER 6	6



https://controleremoto.pt/pt/LG/1068936-98382-comando-de-substituicao-para-LG-AKB74935640.html