Original		Substituto	
POWER	Power	Power	
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
TEXT	Text	GOTO TEXT	Text / Goto
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
TVG	TVG	-/-- GUIDE EPG	Guide / EPG / -/--
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SIZE	Size	SIZE ZOOM	Zoom / Size
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
MEDIA	Media	LIST SMART	Smart / List
SUBPAGE	Subpage	SURROUND	Eject / Surround
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Substituto	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Rec	REC MODE	Rec / Rec Mode
	Stop	HOLD	Stop / Hold
	I<<	PRESET-	I<< / Preset-
MENU	Sleep	TIMER SLEEP	Sleep / Timer
INDEX	>>I / Index	PRESET+	>>I / Preset+
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SLEEP	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -

Original		Substituto	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DISPLAY	Display	MEDIA DISPLAY	Display / Media
+ CH	CH+	+ CH PAGE	CH+ / Page+
CH −	CH-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
⟲	Recall	RETURN BACK	Back / Return
SOURCE	Source	RDS AV INPUT	AV / Input / RDS

Original		Substituto	
P-MODE	P. Mode	FORMAT PICTURE	Picture / Format
S-MODE	S. Mode	TITLE SOUND	Sound / Title