

Original		Substituto	
Power CD		Power	
Power AMP		SHIFT +	Shift + Power
Up CD		Up	
Up AMP		SHIFT +	Shift + Up
Left CD		Left	
Left AMP		SHIFT +	Shift + Left
Enter CD		OK	
Enter AMP		SHIFT + OK	Shift + OK
Right CD		Right	
Right AMP		SHIFT +	Shift + Right
Down CD		Down	
Down AMP		SHIFT +	Shift + Down
Display CD		SMART	Smart / List
Display AMP		SHIFT + SMART	Shift + Smart / List
Mode/Trim CD		FORMAT PICTURE	Picture / Format
Mode/Trim AMP		SHIFT + FORMAT PICTURE	Shift + Picture / Format
Setup CD		OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Substituto	
Setup AMP		SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
Pause		STEP-FREEZE	Pause / Step / Freeze
I<<		PRESET-	I<< / Preset-
Play		SLOW	Play / Slow
>>I		PRESET+	>>I / Preset+
Stop		HOLD	Stop / Hold
Info		ANGLE INFO	Info / Angle
Disc/Input		RDS AV INPUT	AV / Input / RDS
Open/Close		SURROUND	Eject / Surround
Input Up		CH PAGE +	CH+ / Page+
Tone		MEDIA DISPLAY	Display / Media
Volume Up		VOL +	Vol+
Input Down		CH PAGE -	CH- / Page-
Volume Down		VOL -	Vol-
Mute		DIMMER MUTE	Mute / Dimmer
1		TV 1	1
2		DVD 2	2





Original		Substituto		Original	Substituto
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
PROGRAM	Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program		
FILTER	Filter	NETFLIX SEARCH	Red / Netflix / Search		
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title		
DIGITAL OUT	Digital Out	PROGRAM TV/RADIO	TV/Radio /		

