Original		Substituto	
DVD	Power		Power
DRIVE SELECT	Drive Select	HOME SMART	Smart
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DELETE *	Delete	FAV PRE-CH	Pre Ch
INPUT SELECT	Input Select	TIMER AV	AV
PAGE CH+	CH+	+ CH	Ch +
CH-	CH-	CH -	Ch -
ShowView	Showview	PICTURE FORMAT	Format

Original		Substituto	
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
SKIP	I<< Skip	I<<	I<<
SKIP >>I	Skip >>I	>>I	>>I
SLOW/S	<< Slow Search	<<	<<
/SEARCH	Slow Search >>	>>	>>
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY/x1.3	Play	PLAY MODE	Play
i	i	DISPLAY INFO	Info
EXIT	Exit	CLEAR EXIT	Exit
DIRECT NAVIGATOR	Direct Navigator	DISC NAV LIST	List
GUIDE	Guide	GUIDE	Guide
FUNCTION MENU	Function Menu	TOP MENU MENU	Menu
	Up		Up
	Left/<I		Left
OK	OK	OK	Ok
	Right/II>		Right

Original		Substituto	
	Down		Down
OPTION	Option	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	Red	A	Red
	Green	B	Green
CREATE CHAPTER	Yellow/Create Chapter	C	Yellow
MANUAL SKIP	Blue/Manual Skip	D	Blue
REC	Rec	REC MODE	Rec
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
EXT LINK	Ext Link	APP MEDIA	Media
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
AUDIO	Audio	SOUND DUAL	Dual
STATUS	Status	ECO 3D	3D
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
TIME SLIP	Time Slip	E-MANUAL D.MENU	D. Menu
TV	Power Tv	SHIFT +	Shift + Power
AV	AV Tv	SHIFT + TIMER AV	Shift + AV

Original		Substituto	
CH	CH+ Tv	SHIFT + CH	Shift + Ch +
CH	CH- Tv	SHIFT + CH	Shift + Ch -
VOL	Vol + Tv	VOL	Vol +
VOL	Vol - Tv	VOL	Vol -