Original		Substituto		Original		Substituto	
Power		Power		0		0	
Sleep		Sleep / Timer		+10		Guide / EPG / -/--	
Timer Play		Right		CD Play/Pause		Play / Slow	
Open/Close		Eject / Surround		FM/AM		TV/Radio /	
Clock/Timer		Shift +	Sleep / Timer	Stop		Stop / Hold	
1		1		Music Port		Smart / List	
2		2		Vol -		Vol -	
3		3		Vol +		Vol +	
PGM-Auto		Menu / Home		< Album		<< / Tune-	
4		4		Album >		>> / Tune+	
5		5		I<< / Down		I<< / Preset-	
6		6		>>I / Up		>>I / Preset+	
Clear		Exit / Cancel / Clear		Enter		OK	
7		7		Preset EQ		Subtitle / EQ	
8		8		Surround		Shift +	Eject / Surround
9		9		Play Mode		Setup / OPT /	
Del		Shift +	Exit / Cancel / Clear	Remaster		D.Menu / Top Menu	

Original		Substituto		Original	Substituto
D.BASS	D. Bass	TITLE SOUND	Sound / Title		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		