# Mandis shop

Sony RM-DC335

| Original | | Substituto | |
|---|---|---|---|
| CONTINUE | Continue Play | GOTO TEXT | Text / Goto |
| SHUFFLE | Shuffle Play Mod | RDS AV INPUT | AV / Input / RDS |
| PROGRAM | Program Play | OPT-TOOLS SETUP | Setup / OPT / |
| REPEAT | Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| CHECK | Check | MEDIA DISPLAY | Display / Media |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| TIME | Time | TIMER SLEEP | Sleep / Timer |
| FADER | Fader | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |

| Original | | Substituto | |
|---|---|---|---|
| >10 | >10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 10/0 | 10/0 | HDMI-SAT 0 | 0 |
| DISC 1 | Disc 1 | NETFLIX SEARCH | Red / Netflix / Search |
| DISC 2 | Disc2 | APP REPEAT | Green / APP / Repeat |
| DISC 3 | Disc3 | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| DISC 4 | Disc4 | Prime Video RANDOM | Blue / Prime Video / Random |
| DISC 5 | Disc5 | LIST SMART | Smart / List |
| DISC SKIP | Disc Skip | PC FAV MARKER | Fav / Marker / PC |
| ▷ | Play | SLOW ▶ | Play / Slow |
| ⏸ | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| ■ | Stop | HOLD ■ | Stop / Hold |
| AMS ⏮ | I<< AMS | PRESET- ⏮ | I<< / Preset- |
| AMS ⏭ | AMS >>I | PRESET+ ⏭ | >>I / Preset+ |
| ANALOG OUT LEVEL | Analog Out | VOL + | Vol + |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| | Analog Out Level | VOL − | Vol - |