# Mandis shop

RC4870

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| | Rec | REC MODE | Rec / Rec Mode |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| LANG. | Lang | LANG I/II AUDIO | Audio / Lang I/II |
| | Source (Games) | SURROUND | Eject / Surround |
| | Movie-Music-Phot | FORMAT PICTURE | Picture / Format |
| | [≡]. . | SIZE ZOOM | Zoom / Size |
| | */O | TIMER SLEEP | Sleep / Timer |
| | TV | PROGRAM TV/RADIO | TV/Radio / |
| Q. MENU | Q. Menu | TOP MENU D.MENU | D. Menu / Top |
| | [-O-] | OPT-TOOLS SETUP | Setup / OPT / |
| | [≡]/Text | GOTO TEXT | Text / Goto |

| Original | | Substituto | |
|---|---|---|---|
| MENU | Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| i | i | ANGLE INFO | Info / Angle |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Down | | Down |
| BACK | Back | RETURN BACK | Back / Return |
| V | Vol + | VOL | Vol + |
| | World (Violet) | LIST SMART | Smart / List |
| P | PR+ | CH PAGE | CH+ / Page+ |
| V | Vol - | VOL | Vol - |
| | */Q | MEDIA DISPLAY | Display / Media |
| P | PR- | CH PAGE | CH- / Page- |
| 1../@ | 1 | TV 1 | 1 |
| 2abc | 2 | DVD 2 | 2 |

| Original | | Substituto | | Original | Substituto |
|---|---|---|---|---|---|
| 3def | 3 | CD-STB 3 | 3 | | |
| 4ghi | 4 | VIDEO 4 | 4 | | |
| 5jkl | 5 | TAPE 5 | 5 | | |
| 6mno | 6 | TUNER 6 | 6 | | |
| 7pqrs | 7 | AUX-HDD 7 | 7 | | |
| 8tuv | 8 | USB 8 | 8 | | |
| 9wxyz | 9 | BLUETOOTH 9 | 9 | | |
| | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| 0 | 0 | HDMI-SAT 0 | 0 | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | Recall | SHIFT + | RETURN BACK Shift + Back / Return | | |
| | | | | | |
| | | | | | |
| | | | | | |