Mandis shop

Yamaha VR09390

Original		Substituto	
POWER	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PHONO	Phono	DVD 2	2
S	I<< CD	PRESET-	I<< / Preset-
P	>>I CD	PRESET+	>>I / Preset+
PLAY	Play CD	SLOW	Play / Slow
CD	CD	CD-STB 3	3
S	<< CD	TUNE-	<< / Tune-
CH	>> CD	TUNE+	>> / Tune+
PAUSE/STOP	Pause CD	STEP-FREEZE	Pause / Step / Freeze
PAUSE/STOP	Stop CD	HOLD	Stop / Hold
DISC SKIP	Disc Skip CD	SURROUND	Eject / Surround
– PR	Preset- Tuner	CH PAGE –	CH- / Page-
– PR	Preset- Tuner	SHIFT + PRESET-	Shift + I<< / Preset-
ET +	Preset+ Tuner	+ CH PAGE	CH+ / Page+
ET +	Preset+ Tuner	SHIFT + PRESET+	Shift + >>I / Preset+
A/B/C/D/E	A/B/C/D/E Tuner	MEDIA DISPLAY	Display / Media

Original		Substituto	
TUNER	Tuner	TUNER 6	6
DIR A	Dir A Tape	HOME MENU	Menu / Home
DECK A/B	Deck A/B Tape	LIST SMART	Smart / List
DIR B	Dir B Tape	ANGLE INFO	Info / Angle
TAPE	Tape	TAPE 5	5
<<	<< Tape	◀	Left
PLAY	Play Tape	OK	OK
>>	>> Tape	▶	Right
REC/PAUSE	Rec Pause Tape	▲	Up
STOP	Stop Tape	▼	Down
REC MUTE	Rec Mute	DIMMER MUTE	Mute / Dimmer
AUX	AUX	AUX-HDD 7	7
–	Vol -	VOL –	Vol -
+	Vol +	+ VOL	Vol +

https://ordered.pt/pt/Yamaha/10323-108-Controle-Substituto-para-Yamaha-VR330-VR390.html