Mandis shop

LG COV33552407

Original	Substituto
Power	Power
Sleep	SHIFT + Power
Vol +	V+
Vol -	V-
Mute	Mute
F	1 / Setup
Preset/Folder Up	+
Preset/Folder	-
Program/	2 / Menu
Dimmer	9 / Disp
Delete	3 / Exit
Sound Effect	5 / Audio
Repeat	7 / Rep
Info	4 / Mode
I<< / Tuning -	I<
Play	Play / Band
Pause	II Ang

Original	Substituto
>>I / Tuning +	>I
Stop	Stop / Random
RDS	-- / Sear
PTY	0 / Zoom

https://ordenar.pt/p/LG-105538346-mando-substituto-para-LG-COV33552407.html