| Original | Substituto |
|---|---|
| Mute | Mute / Dimmer |
| Power | Power |
| O/F. Set | Sleep / Timer |
| [ ]/F. List | Smart / List |
| Audio | Audio / Lang I/II |
| [+]/Picture | Picture / Format |
| -[ ]←/Rec Menu | D.Menu / Top |
| Radio/Search | TV/Radio / |
| Radio/Search | SHIFT + NETFLIX SEARCH Shift + Red / Netflix / |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |

| Original | Substituto |
|---|---|
| 9 | 9 |
| *EPG | Guide / EPG / -/-- |
| 0/AV | 0 |
| 0/AV | AV / Input / RDS |
| #PIP | Setup / OPT / |
| Text | Text / Goto |
| Menu | Menu / Home |
| End | Exit / Cancel / Clear |
| Info | Info / Angle |
| P+ | CH+ / Page+ |
| Up | Up |
| Vol - | Vol - |
| Left | Left |
| OK | OK |
| Down | Down |
| Vol + | Vol + |
| Right | Right |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| P- | CH- / Page- | | |
| Red/ C- Set | Red / Netflix / Search | | |
| Green/ SV | Green / APP / Repeat | | |
| Yellow/ Title | Sound / Title | | |
| Yellow/ Title | Yellow / YouTube / Repeat | | |
| Blue/ Card | Blue / Prime Video / Random | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |
| Rec | Rec / Rec Mode | | |
| Pause | Pause / Step / Freeze | | |
| Stop | Stop / Hold | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 abc | 2 | DVD 2 | 2 |
| 3 def | 3 | CD - STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX - HDD 7 | 7 |
| 8 tuv | 8 | USB 8 | 8 |
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| DVD-AV * EPG | *EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 AV | 0/AV | RDS AV INPUT | AV / Input / RDS |
| 0 AV | 0/AV | HDMI - SAT 0 | 0 |
| # PIP | #PIP | FORMAT PICTURE | Picture / Format |
| MENU | Menu | HOME MENU | Menu / Home |
| INFO | Info | ANGLE INFO | Info / Angle |

| Original | | Substituto | |
|---|---|---|---|
| P+ | P+ | + CH PAGE | CH+ / Page+ |
| | Up | | Up |
| V- | Vol - | VOL − | Vol - |
| | Left | | Left |
| OK | OK | OK | OK |
| | Down | | Down |
| V+ | Vol + | + VOL | Vol + |
| | Right | | Right |
| P- | P- | CH PAGE − | CH- / Page- |
| C-SET | Red/C-Set | NETFLIX SEARCH | Red / Netflix / Search |
| SV | Green/SV | APP REPEAT | Green / APP / Repeat |
| TITLE | Yellow/Title | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| TITLE | Yellow/Title | TITLE SOUND | Sound / Title |
| CARD | Blue/Card | Prime Video RANDOM | Blue / Prime Video / Random |
| | << | TUNE- | << / Tune- |
| | Play | SLOW | Play / Slow |
| | >> | TUNE+ | >> / Tune+ |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Rec | REC MODE Rec / Rec Mode | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Stop | HOLD Stop / Hold | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Power | | Power |
| SET | O/F. Set | TIMER SLEEP | Sleep / Timer |
| LIST | [ ]/F. List | LIST SMART | Smart / List |
| | Audio/Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| | Audio/Repeat | LANG I/II AUDIO | Audio / Lang I/II |
| | [+]/Picture | FORMAT PICTURE | Picture / Format |
| REC-MENU | →[ ]←/Rec Menu | GOTO TEXT | Text / Goto |
| RADIO | Radio/Search | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| RADIO | Radio/Search | PROGRAM TV/RADIO | TV/Radio / |
| 1 | 1 | TV 1 | 1 |
| 2 abc | 2 | DVD 2 | 2 |
| 3 def | 3 | CD-STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX-HDD 7 | 7 |

| Original | | Substituto | |
|---|---|---|---|
| 8 tuv | 8 | USB 8 | 8 |
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| DVD-AV EPG | DVD-AV | RDS AV INPUT | AV / Input / RDS |
| 0 AV | 0/AV | HDMI-SAT 0 | 0 |
| # PIP | #PIP | OPT-TOOLS SETUP | Setup / OPT / |
| DISC-M TEXT | Disc-M | TOP MENU D.MENU | D.Menu / Top |
| MENU | Menu | HOME MENU | Menu / Home |
| END | End | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| INFO | Info | ANGLE INFO | Info / Angle |
| P+ | P+ | CH PAGE | CH+ / Page+ |
| | Up | | Up |
| V- | Vol - | VOL | Vol - |
| | Left | | Left |
| OK | OK | OK | OK |
| | Down | | Down |
| V+ | Vol + | VOL | Vol + |
| | Right | | Right |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| P- | CH- / Page- | | |
| Red/ C- Set | Red / Netflix / Search | | |
| Green/ SV | Green / APP / Repeat | | |
| Yellow/ Title | Yellow / YouTube / Repeat | | |
| Yellow/ Title | Sound / Title | | |
| Blue/ Card | Blue / Prime Video / Random | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |
| Rec | Rec / Rec Mode | | |
| Pause | Pause / Step / Freeze | | |
| Stop | Stop / Hold | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Power | | Power |
| SET | O/F. Set | TIMER SLEEP | Sleep / Timer |
| LIST | [ ]/F. List | LIST SMART | Smart / List |
| | Audio/Repeat | APP REPEAT | Green / APP / Repeat |
| | Audio/Repeat | LANG I/II AUDIO | Audio / Lang I/II |
| | [+]/Picture | FORMAT PICTURE | Picture / Format |
| REC-MENU | →[ ]←/Rec Menu | TOP MENU D.MENU | D.Menu / Top |
| RADIO | Radio/Search | NETFLIX SEARCH | Red / Netflix / Search |
| RADIO | Radio/Search | PROGRAM TV/RADIO | TV/Radio / |
| 1 | 1 | TV 1 | 1 |
| 2 abc | 2 | DVD 2 | 2 |
| 3 def | 3 | CD-STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX-HDD 7 | 7 |

| Original | | Substituto | |
|---|---|---|---|
| 8 tuv | 8 | USB 8 | 8 |
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| DVD-AV ★ EPG | *EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 AV | 0/AV | HDMI-SAT 0 | 0 |
| 0 AV | 0/AV | RDS AV INPUT | AV / Input / RDS |
| # PIP | #PIP | OPT-TOOLS SETUP | Setup / OPT / |
| MENU | Menu | HOME MENU | Menu / Home |
| END | End | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| INFO | Info | ANGLE INFO | Info / Angle |
| P+ | P+ | CH PAGE | CH+ / Page+ |
| | Up | | Up |
| V- | Vol - | VOL | Vol - |
| | Left | | Left |
| OK | OK | OK | OK |
| | Down | | Down |
| V+ | Vol + | VOL | Vol + |
| | Right | | Right |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| P- | CH- / Page- | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |
| Rec | Rec / Rec Mode | | |
| Pause | Pause / Step / Freeze | | |
| Stop | Stop / Hold | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |