Original		Substituto	
STANDBY/ON	Standby/on	Power	
OPEN/CLOSE	Open/close	SURROUND	Eject / Surround
CD	CD	SHIFT + CD-STB 3	Shift + 3
USB	USB	SHIFT + USB 8	Shift + 8
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
AUDIO IN	Audio In	LANG I/II AUDIO	Audio / Lang I/II
BT AUDIO	BT Audio	SHIFT + BLUETOOTH 9	Shift + 9
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
EQUALIZER	Equalizer	OPT-TOOLS SETUP	Setup / OPT /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
P.BASS	P. Bass	TITLE SOUND	Sound / Title

Original		Substituto	
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
BASS/TREBLE	Bass/Treble	SHIFT + TITLE SOUND	Shift + Sound / Title
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TUNE+	Up/Tune+		Up
FOLDER	Folder	GOTO TEXT	Text / Goto
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
TUNE–	Down/Tune-		Down
MEMORY/ PROGRAM	Memory/Program	PROGRAM TV/ RADIO	TV/Radio / Program

Original	Substituto	Original	Substituto
PRESET + Preset +	PRESET+ >>I / Preset +		
MUTE Mute	DIMMER MUTE Mute / Dimmer		
VOLUME + Vol +	VOL + Vol +		
– Preset -	PRESET- I << / Preset -		
DIMMER Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer		
– Vol -	VOL – Vol -		
<<I <<	TUNE- << / Tune-		
■ Stop	HOLD ■ Stop / Hold		
►/II Play	SLOW ► Play / Slow		
►/II Pause	STEP-FREEZE II Pause / Step / Freeze		
>>I >>I	TUNE+ >> / Tune+		
ST/MONO ST/Mono	SHIFT + LANG I/II AUDIO Shift + Audio / Lang I/II		
RDS ASPM RDS ASPM	SHIFT + LIST SMART Shift + Smart / List		
PTY RDS PTY	LIST SMART Smart / List		
DISPLAY RDS Display	SHIFT + MEDIA DISPLAY Shift + Display / Media		