Original		Substituto	
	Power Tuner		Power
MUTE	Mute		Mute
1	1 Tuner		1
2	2 Tuner	LIST	2
3	3 Tuner		3
4	4 Tuner		4
5	5 Tuner	PROG	5
6	6 Tuner		6
7	7 Tuner		7
8	8 Tuner	SLEEP	8
9	9 Tuner		9
0	0 Tuner	MANU	0
CINEMA GO	Cinema Go		Guide
+	Vol +		Vol +
—	Vol -		Vol -
▶	Play Tuner / Phono/ Cable Box		Play
■	Stop Tuner / Phono/ Cable Box		Stop

Original		Substituto	
LOUDNESS	Loudness		Subt
SUBW. ON/OFF	Subw. On/Off		Smart
VIRTUAL MODE	Mode/ Virtual		Options
NIGHT	Night		3D
SURROUND ON/OFF	Surround On/Off	SC NA	Media
REAR +	Channel / Rear +		Ch +
CHANNEL −	Channel / Rear -		Ch -
SURROUND MODE	Surround Mode		TV/ R
TEST TONE	Test Tone		Exit
SUB WOOFER +	Sub woofer +		Green
SUB WOOFER −	Sub Woofer -		Red
	Right Tuner		Right
	Up Tuner	AY MOD	Up
	Down Tuner		Down
	Left Tuner		Left
OK	OK Tuner		Ok
GUIDE MENU	Menu / Guide	P	Menu

Tuner

Original	Substituto	Original	Substituto
i / News/ TA	Info		
I < Channel / Track	I <<		
Channel / Track >I Tuner	>>I		
Pause/ FR. D.	Pause		
Tuner	+ Shift + Smart		
Phono	+ Shift + Media		
Power Phono	+ Shift + Power		

Original	Substituto
Power Tv	Power
TV	Blue
Mute Tv	Mute
1 Tv	1
2 Tv	2
3 Tv	3
4 Tv	4
5 Tv	5
6 Tv	6
7 Tv	7
8 Tv	8
9 Tv	9
0 Tv	0
Menu/Guide Tv	Menu
OK Tv	Ok
Up Tv	Up
Down Tv	Down

Original	Substituto
Right Tv	Right
Left Tv	Left
Vol + Tv/CD	Vol +
Vol - Tv/CD	Vol -
Play Tv	Play
Stop Tv	Stop
i/News/TA Tv	Info
I< Channel/Track	I <<
Channel/Track >I	>>I
Power CD	+ Shift + Power
CD	Yellow
Mute CD	+ Shift + Mute
1 CD	+ Shift + 1
2 CD	+ Shift + 2
3 CD	+ Shift + 3
4 CD	+ Shift + 4
5 CD	+ Shift + 5

Original	Substituto	Original	Substituto
6 CD	+ Shift + 6		
7 CD	+ Shift + 7		
8 CD	+ Shift + 8		
9 CD	+ Shift + 9		
0 CD	+ Shift + 0		
Up CD	+ Shift + Up		
Down CD	+ Shift + Down		
Right CD	+ Shift + Right		
Left CD	+ Shift + Left		
i / News/ TA CD	+ Shift + Info		
Stop CD	+ Shift + Stop		
Play CD	+ Shift + Play		
I < CD	<<		
>I CD	>>		
Pause/ FR. D. CD	Pause		
: >/ Cancel CD	Exit		
Disc/ DVD CD	Smart		

Original	Substituto
Power SAT	Power
SAT	Yellow
1 SAT	1
2 SAT	2
3 SAT	3
4 SAT	4
5 SAT	5
6 SAT	6
7 SAT	7
8 SAT	8
9 SAT	9
0 SAT	0
Mute SAT	Mute
Vol + SAT/DVD	Vol +
Vol - SAT/DVD	Vol -
Play SAT	Play
Stop SAT	Stop

Original	Substituto
i/News/TA SAT	Info
Menu/Guide	Menu
OK SAT	Ok
Up SAT	Up
Down SAT	Down
Right SAT	Right
Left SAT	Left
I< Channel/Track SAT	I<<
Channel/Track >I SAT	>>I
:>/Cancel SAT	Exit
T·C/Index SAT	Back
Power DVD	+ Shift + Power
DVD	Blue
1 DVD	+ Shift + 1
2 DVD	+ Shift + 2
3 DVD	+ Shift + 3
4 DVD	+ Shift + 4

Original		Substituto		Original		Substituto	
5	5 DVD	+ PROG	Shift + 5	DVD DISC	Disc DVD		Smart
6	6 DVD	+	Shift + 6	REC AUDIO	Audio DVD		Dual
7	7 DVD	+	Shift + 7	CANCEL	:>/ Cancel DVD	+	Shift + Exit
8	8 DVD	+ LEEP	Shift + 8	FR.D.	Pause/ FR. D.		Pause
9	9 DVD	+	Shift + 9	INDEX T-C	T· C/ Index DVD	+	Shift + Back
0	0 DVD	+	Shift + 0				
GUIDE MENU	Menu/ Guide	+ P	Shift + Menu				
OK	OK DVD	+	Shift + Ok				
	Up DVD	+ AY MOD	Shift + Up				
	Down DVD	+	Shift + Down				
	Right DVD	+	Shift + Right				
	Left DVD	+	Shift + Left				
	Play DVD	+	Shift + Play				
	Stop DVD	+	Shift + Stop				
NEWS/TA	i / News/ TA DVD	+	Shift + Info				
CHANNE	I < Channel / Track DVD	<<					
L/TRACK	Channel / Track >I DVD	>>					

Original	Substituto
Power VCR	Power
VCR	Yellow
Mute VCR	Mute
1 VCR	1
2 VCR	2
3 VCR	3
4 VCR	4
5 VCR	5
6 VCR	6
7 VCR	7
8 VCR	8
9 VCR	9
0 VCR	0
Menu/Guide	Menu
Up VCR	Up
OK VCR	Ok
Down VCR	Down

Original	Substituto
Right VCR	Right
Left VCR	Left
Vol + VCR	Vol +
Vol - VCR	Vol -
Play VCR	Play
Stop VCR	Stop
I< Channel/Track VCR	I<<
Channel/Track >I VCR	>>I
Rec VCR	Rec
:>/Cancel VCR	Exit
Pause/FR.D VCR	Pause
T·C/Index VCR	Back
Power	+ Shift + Power
CDR/Tape	Blue
1 CDR/Tape	+ Shift + 1
2 CDR/Tape	+ Shift + 2
3 CDR/Tape	+ Shift + 3

Original	Substituto	Original	Substituto
4 CDR/Tape	+ Shift + 4	Disc CDR/Tape	Smart
5 CDR/Tape	+ Shift + 5		
6 CDR/Tape	+ Shift + 6		
7 CDR/Tape	+ Shift + 7		
8 CDR/Tape	+ Shift + 8		
9 CDR/Tape	+ Shift + 9		
0 CDR/Tape	+ Shift + 0		
Up CDR/Tape	+ Shift + Up		
Down CDR/Tape	+ Shift + Down		
Right CDR/Tape	+ Shift + Right		
Left CDR/Tape	+ Shift + Left		
i / News/TA	Info		
I< Channel / Track CDR/Tape	+ Shift + I<<		
Channel / Track >I CDR/Tape	+ Shift + >>I		
Rec CDR/Tape	+ Shift + Rec		
: >/ Cancel	+ Shift + Exit		
Pause/FR. D. CDR/Tape	+ Shift + Pause		