Original	Substituto
Power Recei ver	Power
Enter Recei ver	Ok
Up Recei ver	Up
Down Recei ver	Down
Ri ght Recei ver	Ri ght
Left Recei ver	Left
Return Recei ver	Back
Q/ Set up Recei ver	Smart
Home/ Audi o	Medi a
Pl ay Recei ver	Pl ay
I << Recei ver	I <<
>>I Recei ver	>>I
<< Recei ver	<<
>> Recei ver	>>
Pause Recei ver	Pause
St op Recei ver	St op
1 Recei ver	1

Original	Substituto
2 Recei ver	2
3 Recei ver	3
4 Recei ver	4
5 Recei ver	5
6 Recei ver	6
7 Recei ver	7
8 Recei ver	8
9 Recei ver	9
0/ 11 Recei ver	0
+10/ - - / - - 10/ Di mm er/ D. Tun Recei ve	Shi ft + Gui de
CLR/ Sl eep/ 12 Recei ver	Pre Ch
Movi e Tv/ Red/ Search	Red
Musi c/ Green/ Repe at Recei ver	Green
Game/ Yel l ow/ Ran dom Recei ver	Yel l ow
St ereo/ Bl ue/ Mode Recei ver	Bl ue
Vol + Recei ver	Vol +
Vol - Recei ver	Vol -

Original		Substituto	
CH Disc/Album+ Receiver		Ch +	
CH Disc/Album- Receiver		Ch -	
Power Tv		Shift +	Power
Input Tv		AV	
CH+ Tv		Shift +	Ch +
CH- Tv		Shift +	Ch -
Up Tv		Shift +	Up
Enter Tv		Shift +	Ok
Down Tv		Shift +	Down
Right Tv		Shift +	Right
Left Tv		Shift +	Left
Menu/Prev CH		Menu	
Top Menu/Guide		Shift +	Menu
Return Tv		Shift +	Back
Q/Setup Tv		Shift +	Smart
Red Tv		Options	
Green Tv		Dual	

Original		Substituto	
Yellow Tv		Subt	
Blue Tv		TV/R	
1 Tv		Shift +	1
2 Tv		Shift +	2
3 Tv		Shift +	3
4 Tv		Shift +	4
5 Tv		Shift +	5
6 Tv		Shift +	6
7 Tv		Shift +	7
8 Tv		Shift +	8
9 Tv		Shift +	9
0/11 Tv		Shift +	0
+10/--/--10 Tv		Guide	
CLR/Sleep/12		Shift +	Pre Ch
Vol + Tv		Shift +	Dual
Vol - Tv		Shift +	Options
AUX		Text	

Original		Substituto	
TV/ CD		Format	
CBL/ SAT		3D	
FM		SHIFT + SUBT Shift + Subt	
NET		SHIFT + MEDIA Shift + Media	
PC		SHIFT + TV/R Shift + TV/ R	
BD/ DVD		SHIFT + TEXT Shift + Text	
USB		SHIFT + AV Shift + AV	

Original		Substituto	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Substituto	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tuning Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original		Substituto	
CBL/SAT	CBL/ SAT	REPEAT TEXT	Text
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL −	Vol -
SOURCE	Power CBL/ SAT	SHIFT +	Shi ft + Power
CH DISC	CH Di sc/ Al bum+ CBL/ SAT	+ CH	Ch +
ALBUM	CH Di sc/ Al bum- CBL/ SAT	CH −	Ch -
MENU PREV CH	Menu/ Prev CH CBL/ SAT	SHIFT + TOP MENU MENU	Shi ft + Menu
TOP MENU GUIDE	Top Menu/ Gui de CBL/ SAT	SHIFT + SETTINGS OPT	Shi ft + Opti ons
RETURN	Return CBL/ SAT	SHIFT + RETURN BACK	Shi ft + Back
Q SETUP	Q/ Set up	SHIFT + HOME SMART	Shi ft + Smart
	Up CBL/ SAT	SHIFT +	Shi ft + Up
ENTER	Enter CBL/ SAT	SHIFT + OK	Shi ft + Ok
	Down CBL/ SAT	SHIFT +	Shi ft + Down
	Ri ght CBL/ SAT	SHIFT +	Shi ft + Ri ght
	Left CBL/ SAT	SHIFT +	Shi ft + Left
	Pause CBL/ SAT	SHIFT +	Shi ft + Pause
	Stop CBL/ SAT	SHIFT +	Shi ft + Stop

Original		Substituto	
	<< CBL/ SAT	SHIFT + CH −	Shi ft + Ch -
	>> CBL/ SAT	SHIFT + + CH	Shi ft + Ch +
PLAY	Pl ay CBL/ SAT	ECO 3D	3D
SEARCH MOVIE/TV A	Movi e Tv/ Red/ Search	SOUND DUAL	Dual
REPEAT MUSIC B	Musi c/ Green/ Repe at CBL/ SAT	AD SUBT	Subt
RANDOM GAME C	Game/ Yel l ow/ Ran dom CBL/ SAT	TIMER AV	AV
MODE STEREO D	Stereo/ Bl ue/ Mode CBL/ SAT	PICTURE FORMAT	For mat
1	1 CBL/ SAT	SHIFT + 1	Shi ft + 1
2	2 CBL/ SAT	SHIFT + 2	Shi ft + 2
3	3 CBL/ SAT	SHIFT + 3	Shi ft + 3
4	4 CBL/ SAT	SHIFT + 4	Shi ft + 4
5	5 CBL/ SAT	SHIFT + 5	Shi ft + 5
6	6 CBL/ SAT	SHIFT + 6	Shi ft + 6
7	7 CBL/ SAT	SHIFT + 7	Shi ft + 7
8	8 CBL/ SAT	SHIFT + 8	Shi ft + 8
9	9 CBL/ SAT	SHIFT + 9	Shi ft + 9
11 0	0/ 11 CBL/ SAT	SHIFT + 0	Shi ft + 0

Original	Substituto	Original	Substituto
BD/ DVD	TV/ R		

Original	Substituto
Power TV/CD	Power
CH/Disc+ TV/CD	Ch +
CH/Disc TV/CD	Ch -
Return TV/CD	Back
Q/Setup TV/CD	Smart
Home/Audio	Media
Up TV/CD	Up
Down TV/CD	Down
Right TV/CD	Right
Left TV/CD	Left
Enter TV/CD	Ok
I<< TV/CD	I<<
>>I TV/CD	>>I
<< TV/CD	<<
>> TV/CD	>>
Play TV/CD	Play
Pause TV/CD	Pause

Original	Substituto
Stop TV/CD	Stop
Movie Tv/Red/Search	Red
Music/Green/Repeat TV/CD	Green
Game/Yellow/Random TV/CD	Yellow
Stereo/Blue/Mode TV/CD	Blue
1 TV/CD	1
2 TV/CD	2
3 TV/CD	3
4 TV/CD	4
5 TV/CD	5
6 TV/CD	6
7 TV/CD	7
8 TV/CD	8
9 TV/CD	9
0/11 TV/CD	0
+10/--/--10/D.Tu Dimmer TV/CD	Guide
CLR/Sleep/12	Pre Ch

Original		Substituto		Original		Substituto	
	Vol + Recei ver		Vol +				
	Vol - Recei ver		Vol -				
	TV/ CD		TV/ R				

Original	Substituto	Original	Substituto
Power Receiver Zone 2	Power	<< Zone 2	<<
Vol + Zone 2	Vol +	Pause Zone 2	Pause
Vol - Zone 2	Vol -	Stop Zone 2	Stop
CH Disc/Album+ Zone 2	Ch +	Movie Tv/Red/Search	Red
CH Disc/Album- Zone 2	Ch -	Music/Green/Repeat Zone 2	Green
Up Zone 2	Up	Game/Yellow/Random Zone 2	Yellow
Enter Zone 2	Ok	Stereo/Blue/Mode Zone 2	Blue
Down Zone 2	Down	1 Zone 2	1
Right Zone 2	Right	2 Zone 2	2
Left Zone 2	Left	3 Zone 2	3
Return Zone 2	Back	4 Zone 2	4
Q/Setup Zone 2	Smart	5 Zone 2	5
Home/Audio Zone	Media	6 Zone 2	6
I << Zone 2	I <<	7 Zone 2	7
>>I Zone 2	>>I	8 Zone 2	8
Play Zone 2	Play	9 Zone 2	9
>> Zone 2	>>	0/11 Zone 2	0

Original	Substituto	Original	Substituto
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		