Original		Substituto		Original		Substituto	
	Power Source	SHIFT +	Shift + Power	USB	USB	SHIFT + 8	Shift + 8
	Power Receiver		Power	NET	NET	SHIFT + 0	Shift + 0
1	HDMI 1	SHIFT + 1	Shift + 1	PHONO	Phono	SHIFT + 9	Shift + 9
2	HDMI 2	SHIFT + 2	Shift + 2	PARTY	Party	AV INPUT	AV / Input / RDS
3	HDMI 3	SHIFT + 3	Shift + 3	HDMI OUT	HDMI Out	SMART	Smart / List
4	HDMI 4	SHIFT + 4	Shift + 4	BD DVD	Scene BD/DVD	NETFLIX	Red / Netflix / Search
5	HDMI 5	SHIFT + 5	Shift + 5	TV	Scene TV	APP	Green / APP / Repeat
V-AUX	V-AUX	SHIFT + 7	Shift + 7	NET	Scene NET	YouTube	Yellow / YouTube / Repeat
1	AV 1	SHIFT + NETFLIX	Shift + Red / Netflix /	RADIO	Scene Radio	Prime Video	Blue / Prime Video / Random
2	AV 2	SHIFT + APP	Shift + Green / APP /	PROGRAM	Program Up	CH PAGE +	CH+ / Page+
3	AV 3	SHIFT + YouTube	Shift + Yellow / YouTube /	VOLUME	Vol +	VOL +	Vol +
4	AV 4	SHIFT + Prime Video	Shift + Blue / Prime	PROGRAM	Program Down	CH PAGE −	CH- / Page-
5	AV 5	SHIFT + GUIDE	Shift + Guide / EPG / -/--	VOLUME	Vol -	VOL −	Vol -
6	AV 6	SHIFT + FAV MARKER	Shift + Fav / Marker / PC	TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
1	Audio 1	TITLE SOUND	Sound / Title	POP-UP/MENU	Pop-Up/Menu	HOME MENU	Menu / Home
2	Audio 2	LANG I/II AUDIO	Audio / Lang I/II	ON SCREEN	On Screen	GOTO TEXT	Text / Goto
TUNER	Tuner	SHIFT + 6	Shift + 6		Up		Up

Original		Substituto	
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	SHIFT + OK	Shift + OK
■	Stop	HOLD ■	Stop / Hold
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
BAND ►	Play/Band	SLOW ▶	Play / Slow
TUN ◀◀	<< Tuning	TUNE- ◀◀	<< / Tune-
JING ►►	Tuning >>	TUNE+ ►►	>> / Tune+
PRE ⏮	I<< Preset	PRESET- ⏮	I<< / Preset-
ESET ⏭	Preset >>I	PRESET+ ⏭	>>I / Preset+
MOVIE	Movie	SHIFT + MEDIA DISPLAY	Shift + Display / Media
MUSIC	Music	SHIFT + LIST SMART	Shift + Smart / List

Original		Substituto	
SUR. DECODE	Sur. Decode	SURROUND ⏏	Eject / Surround
STRAIGHT	Straight	EQ SUBTITLE	Subtitle / EQ
INFO	Info	ANGLE INFO	Info / Angle
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ENHANCER	Enhancer	FORMAT PICTURE	Picture / Format
PURE DIRECT	Pure Direct	SIZE ZOOM	Zoom / Size
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEMORY +10	+10/Memory	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Substituto	Original	Substituto
ENT	Fav / Marker / PC		
Mute	Mute / Dimmer		

Original		Substituto	
	Power Source	SHIFT +	Shift + Power
	Power Receiver		Power
1	HDMI 1	SHIFT + TV 1	Shift + 1
2	HDMI 2	SHIFT + DVD 2	Shift + 2
3	HDMI 3	SHIFT + CD-STB 3	Shift + 3
4	HDMI 4	SHIFT + VIDEO 4	Shift + 4
5	HDMI 5	SHIFT + TAPE 5	Shift + 5
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
1	AV 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
2	AV 2	SHIFT + APP REPEAT	Shift + Green / APP /
3	AV 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
4	AV 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
5	AV 5	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
6	AV 6	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
1	Audio 1	TITLE SOUND	Sound / Title
2	Audio 2	LANG I/II AUDIO	Audio / Lang I/II
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6

Original		Substituto	
USB	USB	SHIFT + USB 8	Shift + 8
NET	NET	SHIFT + HDMI-SAT 0	Shift + 0
PHONO	Phono	SHIFT + BLUETOOTH 9	Shift + 9
PARTY	Party	RDS AV INPUT	AV / Input / RDS
HDMI OUT	HDMI Out	LIST SMART	Smart / List
BD DVD	Scene BD/DVD	NETFLIX SEARCH	Red / Netflix / Search
TV	Scene TV	APP REPEAT	Green / APP / Repeat
NET	Scene NET	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RADIO	Scene Radio	Prime Video RANDOM	Blue / Prime Video / Random
+ VOLUME	Vol +	+ VOL	Vol +
VOLUME –	Vol -	VOL –	Vol -
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
POP-UP/MENU	Pop-Up/Menu	HOME MENU	Menu / Home
ON SCREEN	On Screen	GOTO TEXT	Text / Goto
▲	Up	▲	Up
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
◀	Left	◀	Left

Original		Substituto	
ENTER	Enter	OK	OK
▶	Right	▶	Right
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	SHIFT + OK	Shift + OK
■	Stop	HOLD ■	Stop / Hold
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
BAND ▶	Play/Band	SLOW ▶	Play / Slow
TUN ◀◀	<< Tuning	TUNE- ◀◀	<< / Tune-
JING ▶▶	Tuning >>	TUNE+ ▶▶	>> / Tune+
PRE ⏮	I<< Preset	PRESET- ⏮	I<< / Preset-
ESET ⏭	Preset >>I	PRESET+ ⏭	>>I / Preset+
INFO	Info	ANGLE INFO	Info / Angle
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2

Original		Substituto	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEMORY +10	+10/Memory	-/-- GUIDE EPG	Guide / EPG / -/--
ENT	ENT	PC FAV MARKER	Fav / Marker / PC
MUTE	Mute	DIMMER MUTE	Mute / Dimmer