Mandis shop

Sony RMSR5

Original		Substituto		Original		Substituto	
DISC SKIP	Disc Skip	Prime Video / RANDOM	Blue / Prime Video / Random		Stop MD	SHIFT + HOLD	Shift + Stop /
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	LOOP	Loop	LIST SMART	Smart / List
I/⏻	Power		Power	FLASH	Flash	ANGLE INFO	Info / Angle
CD	CD Play	SLOW ▶	Play / Slow	FUNCTION	Function	HOME MENU	Menu / Home
	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze	FILE SELECT	Up	▲	Up
	Stop	HOLD ■	Stop / Hold	VOL	Vol +	+ VOL	Vol +
TUNER/BAND	Tuner/Band	YouTube / REPEAT A-B	Yellow / YouTube / Repeat	ON/OFF	On / Off	OK	OK
	I<<	PRESET- ⏮	I<< / Preset-		Down	▼	Down
	>>I	PRESET+ ⏭	>>I / Preset+		Vol -	VOL −	Vol -
DECK A	Deck A Play	NETFLIX / SEARCH	Red / Netflix / Search				
	<<	TUNE- ◀◀	<< / Tune-				
	>>	TUNE+ ▶▶	>> / Tune+				
DECK B	Deck B Play	APP / REPEAT	Green / APP / Repeat				
CHECK	Check	MEDIA / DISPLAY	Display / Media				
CLEAR	Clear	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear				
MD	MD Play	SHIFT + SLOW ▶	Shift + Play /				
	Pause MD	SHIFT + STEP-FREEZE ⏸	Shift + Pause / Step / Freeze				

https://ordered.pt/pt/Sony/1365-310-mandes-substituicoes-para-Sony-RMSR5-1475211.htm