| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| PLAY | Play | SLOW | Play / Slow |
| PAUSE | Pause | STEP·FREEZE | Pause / Step / Freeze |
| STOP | Stop | HOLD | Stop / Hold |
| SEARCH | << Search | TUNE- | << / Tune- |
| SEARCH | Search >> | TUNE+ | >> / Tune+ |
| SKIP | I<< Skip | PRESET- | I<< / Preset- |
| SKIP | Skip >>I | PRESET+ | >>I / Preset+ |
| RE-MASTER | Re-Master | TITLE SOUND | Sound / Title |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| OPEN/CLOSE | Open/Close | SURROUND | Eject / Surround |
| PIP | PIP | FORMAT PICTURE | Picture / Format |
| DRIVE SELECT | Select/Drive | TOP MENU D.MENU | D.Menu / Top |
| OPTION | Option | OPT-TOOLS SETUP | Setup / OPT / |
| VIERA CAST | Cast/Vieta | GOTO TEXT | Text / Goto |
| AV | AV Tv | RDS AV INPUT | AV / Input / RDS |
| FUNCTION MENU | Function Menu | HOME MENU | Menu / Home |

| Original | | Substituto | |
|---|---|---|---|
| | Up | | Up |
| | Left/<II | | Left |
| OK | OK | OK | OK |
| | Right/II> | | Right |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| VOL | Vol + Tv | VOL | Vol + |
| DIRECT NAVIGATOR TOP MENU | Top Menu/Direct Navigator | LIST SMART | Smart / List |
| CH | CH+ Tv | CH PAGE | CH+ / Page+ |
| VOL | Vol - Tv | VOL | Vol - |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| CH | CH- Tv | CH PAGE | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2abc | 2 | DVD 2 | 2 |
| 3def | 3 | CD-STB 3 | 3 |
| 4ghi | 4 | VIDEO 4 | 4 |

| Original | | Substituto | |
|---|---|---|---|
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX - HDD 7 | 7 |
| 8 tuv | 8 | USB 8 | 8 |
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| | Power Tv | SHIFT + | Shift + Power |
| STATUS | Status | SHIFT + OPT-TOOLS SETUP | Shift + Setup / OPT / Tools |
| CANCEL | Cancel | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |
| RECEIVER VOL + | Vol + Receiver | SHIFT + VOL + | Shift + Vol + |
| POP-UP MENU | Pop-Up Menu | SHIFT + LIST SMART | Shift + Smart / List |
| | Vol - Receiver | SHIFT + VOL - | Shift + Vol - |

| Original | Substituto |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |