Original	Substituto
Power MD	Power
Power TV	SHIFT + Power
TV	NETFLIX SEARCH: Red / Netflix / Search
VCR	SHIFT + APP REPEAT: Shift + Green / APP /
Tuner/Band	APP REPEAT: Green / APP / Repeat
Play MD	SLOW: Play / Slow
Tape	SHIFT + NETFLIX SEARCH: Shift + Red / Netflix /
MD	SHIFT + YouTube REPEAT A-B: Shift + Yellow / YouTube /
CD	YouTube REPEAT A-B: Yellow / YouTube / Repeat
<<|/ << MD	TUNE-: << / Tune-
<<|/ << MD	PRESET-: |<< / Preset-
Stop MD	HOLD: Stop / Hold
>>|/ >>| MD	PRESET+: >>| / Preset+
>>|/ >>| MD	TUNE+: >> / Tune+
Top Menu/Disc/Deck	TOP MENU D.MENU: D.Menu / Top
Up	Up
DVD	Prime Video RANDOM: Blue / Prime Video / Random

Original	Substituto
Left	Left
Enter	OK
Right	Right
Display	MEDIA DISPLAY: Display / Media
Down	Down
Menu	HOME MENU: Menu / Home
Stereo	LANG I/II AUDIO: Audio / Lang I/II
Surround	SURROUND: Eject / Surround
SFC	EQ SUBTITLE: Subtitle / EQ
Test	GOTO TEXT: Text / Goto
Delay	RETURN BACK: Back / Return
Level	LIST SMART: Smart / List
-	CH PAGE -: CH- / Page-
+	CH PAGE +: CH+ / Page+
1 MD	TV 1: 1
1 Tv	SHIFT + TV 1: Shift + 1
2 MD	DVD 2: 2

Original	Substituto
2 Tv	SHIFT + DVD 2 — Shift + 2
3 MD	CD-STB 3 — 3
3 Tv	SHIFT + CD-STB 3 — Shift + 3
4 MD	VIDEO 4 — 4
4 Tv	SHIFT + VIDEO 4 — Shift + 4
5 MD	TAPE 5 — 5
5 Tv	SHIFT + TAPE 5 — Shift + 5
6 MD	TUNER 6 — 6
6 Tv	SHIFT + TUNER 6 — Shift + 6
≥10/-/-- MD	-/-- GUIDE EPG — Guide / EPG / -/--
≥10/-/-- Tv	SHIFT + -/-- GUIDE EPG — Shift + Guide / EPG / -/--
7 MD	AUX-HDD 7 — 7
7 Tv	SHIFT + AUX-HDD 7 — Shift + 7
8 MD	USB 8 — 8
8 Tv	SHIFT + USB 8 — Shift + 8
9 MD	BLUETOOTH 9 — 9
9 Tv	SHIFT + BLUETOOTH 9 — Shift + 9

Original	Substituto
0 MD	HDMI-SAT 0 — 0
0 Tv	SHIFT + HDMI-SAT 0 — Shift + 0
Tv Vol Down	SHIFT + VOL − — Shift + Vol -
Tv Vol Up	SHIFT + + VOL — Shift + Vol +
Tv/AV	RDS AV INPUT — AV / Input / RDS
Muting	DIMMER MUTE — Mute / Dimmer
Vol -	VOL − — Vol -
Vol +	+ VOL — Vol +

Original	Substituto
Power DVD	Power
TV	Red / Netflix / Search
TV	Shift + 1
VCR	Shift + 4
VCR	Shift + Green / APP /
Tuner / Band	Green / APP / Repeat
Tuner / Band	Shift + 6
Play DVD	Play / Slow
Tape	Shift + Red / Netflix /
Tape	Shift + 5
MD	Shift + Yellow / YouTube /
CD	Shift + 3
CD	Yellow / YouTube / Repeat
I <<| << DVD	<< / Tune-
I <<| << DVD	I << / Preset-
Stop DVD	Stop / Hold
>>| >>I DVD	>>I / Preset+

Original	Substituto
>>| >>I DVD	>> / Tune+
Top Menu/ Disc/ Deck	D. Menu / Top
Up	Up
DVD	Blue / Prime Video / Random
DVD	Shift + 2
Left	Left
Enter	OK
Right	Right
Display	Display / Media
Down	Down
Menu	Menu / Home
Stereo	Audio / Lang I/II
Surround	Eject / Surround
SFC	Subtitle / EQ
Test	Text / Goto
Delay	Back / Return
Level	Smart / List

Original		Substituto		Original	Substituto
	-	CH PAGE –	CH- / Page-		
	+	+ CH PAGE	CH+ / Page+		
1	1 DVD	TV 1	1		
2	2 DVD	DVD 2	2		
3	3 DVD	CD - STB 3	3		
4	4 DVD	VIDEO 4	4		
5	5 DVD	TAPE 5	5		
6	6 DVD	TUNER 6	6		
≥10/-/--	>10/ - / - - DVD	-/-- GUIDE EPG	Guide / EPG / - / - -		
7	7 DVD	AUX - HDD 7	7		
8	8 DVD	USB 8	8		
9	9 DVD	BLUETOOTH 9	9		
0	0 DVD	HDMI - SAT 0	0		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
– VOL	Vol -	VOL –	Vol -		
VOL +	Vol +	+ VOL	Vol +		

Original	Substituto
Power CD	Power
Power Tape	Shift + Power
TV	Red / Netflix / Search
TV	Shift + 1
VCR	Shift + Green / APP /
VCR	Shift + 4
Tuner / Band	Green / APP / Repeat
Tuner / Band	Shift + 6
Play CD	Play / Slow
Play Tape	Shift + Play /
Tape	Shift + Red / Netflix /
Tape	Shift + 5
MD	Shift + Yellow / YouTube /
CD	Yellow / YouTube / Repeat
CD	Shift + 3
I <<| << CD	<< / Tune-
I <<| << Tape	Shift + << / Tune-

Original	Substituto
I <<| << CD	I << / Preset-
I <<| << Tape	Shift + I << / Preset-
Stop CD	Stop / Hold
Stop Tape	Shift + Stop /
>>| >>I CD	>>I / Preset+
>>| >>I Tape	Shift + >> /
>>| >>I CD	>> / Tune+
>>| >>I Tape	Shift + >>I / Preset+
Top Menu/ Disc/ Deck	D. Menu / Top
Top Menu/ Disc/ Deck	Shift + D. Menu / Top Menu
Up	Up
DVD	Blue / Prime Video / Random
DVD	Shift + 2
Left	Left
Enter	OK
Right	Right
Display	Display / Media

Original		Substituto	
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
SFC	SFC	EQ SUBTITLE	Subtitle / EQ
TEST	Test	GOTO TEXT	Text / Goto
DELAY	Delay	RETURN BACK	Back / Return
LEVEL	Level	LIST SMART	Smart / List
–	-	CH PAGE –	CH- / Page-
+	+	+ CH PAGE	CH+ / Page+
1	1 CD-Tape	TV 1	1
2	2 CD-Tape	DVD 2	2
3	3 CD-Tape	CD-STB 3	3
DIRECT TUNING/ DISC ENTER	Direct Tuning/Disc Ente	OPT-TOOLS SETUP	Setup / OPT /
4	4 CD-Tape	VIDEO 4	4
5	5 CD-Tape	TAPE 5	5
6	6 CD-Tape	TUNER 6	6

Original		Substituto	
≥10/-/--	>10/-/-- CD-Tape	-/-- GUIDE EPG	Guide / EPG / -/--
7	7 CD-Tape	AUX-HDD 7	7
8	8 CD-Tape	USB 8	8
9	9 CD-Tape	BLUETOOTH 9	9
0	0 CD-Tape	HDMI-SAT 0	0
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
– VOL	Vol -	VOL –	Vol -
VOL +	Vol +	+ VOL	Vol +

Original	Substituto
Power VCR	SHIFT + Power (Shift + Power)
Power Tuner/Band	Power
TV	NETFLIX SEARCH (Red / Netflix / Search)
VCR	SHIFT + APP REPEAT (Shift + Green / APP / Green / APP / Repeat)
Tuner/Band	APP REPEAT
Play	SLOW (Play / Slow)
Tape	SHIFT + NETFLIX SEARCH (Shift + Red / Netflix / Shift + Yellow / YouTube /)
MD	SHIFT + YouTube REPEAT A-B
CD	YouTube REPEAT A-B (Yellow / YouTube / Repeat)
I<<<I / <<	TUNE- (<< / Tune-)
Stop	HOLD (Stop / Hold)
>>I / >>I	TUNE+ (>> / Tune+)
Top Menu/Disc/Deck	TOP MENU D.MENU (D. Menu / Top)
Up	Up
DVD	Prime Video RANDOM (Blue / Prime Video / Random)
Left	Left
Enter	OK

Original	Substituto
Right	Right
Display	MEDIA DISPLAY (Display / Media)
Down	Down
Menu	HOME MENU (Menu / Home)
Stereo	LANG I/II AUDIO (Audio / Lang I/II)
Surround	SURROUND (Eject / Surround)
SFC	EQ SUBTITLE (Subtitle / EQ)
Test	GOTO TEXT (Text / Goto)
Delay	RETURN BACK (Back / Return)
Level	LIST SMART (Smart / List)
-	CH PAGE - (CH- / Page-)
+	CH PAGE + (CH+ / Page+)
1 VCR	SHIFT + TV 1 (Shift + 1)
1 Tuner/Band	TV 1 (1)
2 VCR	SHIFT + DVD 2 (Shift + 2)
2 Tuner/Band	DVD 2 (2)
3 VCR	SHIFT + CD-STB 3 (Shift + 3)

Original	Substituto
3 Tuner / Band	3
Direct Tuning/ Disc Ente	Setup / OPT /
4 VCR	SHIFT + 4
4 Tuner / Band	4
5 VCR	SHIFT + 5
5 Tuner / Band	5
6 VCR	SHIFT + 6
6 Tuner / Band	6
>10/ - / - - VCR	SHIFT + GUIDE EPG (Shift + Guide / EPG / - / - -)
>10/ - / - -	GUIDE EPG (Guide / EPG / - / - -)
7 VCR	SHIFT + 7
7 Tuner / Band	7
8 VCR	SHIFT + 8
8 Tuner / Band	8
9 VCR	SHIFT + 9
9 Tuner / Band	9
0 VCR	SHIFT + 0

Original	Substituto
0 Tuner / Band	0
Muting	Mute / Dimmer
Vol -	Vol -
Vol +	Vol +