Original		Substituto	
ON/STANDBY	On / Standby	Power	
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
MUTING	Muting	MUTE	Mute
CH DISC	CH +	CH +	Ch +
ALBUM	CH -	CH −	Ch -
VOL	Vol +	VOL +	Vol +
VOL	Vol -	VOL −	Vol -
GUIDE/TOP MENU	Guide / Top Menu	E-MANUAL D.MENU	D. Menu
GUIDE/TOP MENU	Guide / Top Menu	SHIFT + TOP MENU MENU	Shift + Menu

Original		Substituto	
GUIDE/TOP MENU	Guide / Top Menu	GUIDE	Guide
PREV CH/MENU	Prev CH / Menu	TOP MENU MENU	Menu
PREV CH/MENU	Prev CH / Menu	FAV PRE-CH	Pre Ch
	Up		Up
PLAYLIST /CATEGORY	Left / Playlist/Category		Left
ENTER	Enter	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
RETURN	Return	RETURN BACK	Back
	I<<		I<<
	>>I		>>I
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause / Play Reverse		Pause

Original		Substituto	
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Search	A	Red
MOVIE/TV SEARCH	Movie/TV / Search	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Substituto	
11 0	0	0	0
--/---10 +10 D.TUN DIMMER	+10 / Dimmer	SHIFT + -/-- GUIDE	Shift + Guide
--/---10 +10 D.TUN DIMMER	D.Tun Tuner	APP MEDIA	Media
12 CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
12 CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original	Substituto
On/Standby	Power
Input BD/DVD	Shift + 1
Input VCR/DVR	Shift + 2
Input CBL/SAT	Shift + 3
Input Game	Shift + 4
Input AUX	Shift + 5
Input Tuner	Shift + 6
Input TV/CD	Shift + 7
Input Port	Shift + 8
Muting	Mute
Vol +	Vol +
Vol -	Vol -
On/Standby	Shift + Power
Display BD/DVD	Info
Guide / Top Menu BD/DVD	Shift + Menu
Guide / Top Menu BD/DVD	D. Menu
Guide / Top Menu BD/DVD	Guide

Original	Substituto
Prev CH / Menu BD/DVD	Menu
Prev CH / Menu BD/DVD	Pre Ch
Up BD/DVD	Up
Left / Playlist/Category	Left
Enter BD/DVD	Ok
Right / Playlist/Category	Right
Down BD/DVD	Down
Setup BD/DVD	Options
Audio BD/DVD	Dual
Return BD/DVD	Back
I<< BD/DVD	I<<
>>I BD/DVD	>>I
<< BD/DVD	<<
Play BD/DVD	Play
>> BD/DVD	>>
Pause BD/DVD	Pause
Stop BD/DVD	Stop

Original	Substituto
MOVIE/TV SEARCH — Movie/TV / Search BD/DVD	A — Red
MOVIE/TV SEARCH — Movie/TV / Search BD/DVD	SEARCH TV/R — TV/R
MUSIC REPEAT — Music / Repeat BD/DVD	B — Green
MUSIC REPEAT — Music / Repeat BD/DVD	REPEAT TEXT — Text
GAME RANDOM — Game / Random BD/DVD	C — Yellow
STEREO PLAY MODE — Stereo / Play Mode BD/DVD	D — Blue
STEREO PLAY MODE — Stereo / Play Mode BD/DVD	SHIFT + PLAY MODE ▶ — Shift + Play
1 — 1 BD/DVD	1 — 1
2 — 2 BD/DVD	2 — 2
3 — 3 BD/DVD	3 — 3
4 — 4 BD/DVD	4 — 4
5 — 5 BD/DVD	5 — 5
6 — 6 BD/DVD	6 — 6
7 — 7 BD/DVD	7 — 7
8 — 8 BD/DVD	8 — 8
9 — 9 BD/DVD	9 — 9
11 0 — 0 BD/DVD	0 — 0

Original	Substituto
--/--10 +10 D.TUN DIMMER — +10 / Dimmer	SHIFT + -/-- GUIDE — Shift + Guide
12 CLR SLEEP — CLR / Sleep	CLEAR EXIT — Exit
12 CLR SLEEP — CLR / Sleep	PROG SLEEP — Sleep

Original		Substituto	
ON/STANDBY	On / Standby	Power	
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input Aux	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
MUTING	Muting	MUTE	Mute
VOL	Vol +	VOL +	Vol +
VOL	Vol -	VOL -	Vol -
ON/STANDBY	On / Standby	SHIFT + Power	Shift + Power
DISPLAY	Display TV/CD	DISPLAY INFO	Info
CH DISC	Disc + / Album + TV/CD	CH +	Ch +
ALBUM	Disc - / Album - TV/CD	CH -	Ch -
	Up TV/CD		Up

Original		Substituto	
PLAYLIST /CATEGORY	Left / Playlist/Category		Left
ENTER	Enter TV/CD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category		Right
	Down TV/CD		Down
SETUP	Setup TV/CD	SETTINGS OPT	Options
AUDIO	Audio TV/CD	SOUND DUAL	Dual
RETURN	Return TV/CD	RETURN BACK	Back
	I<< TV/CD		I<<
	>>I TV/CD		>>I
	<< TV/CD		<<
	>> TV/CD		>>
	Play TV/CD	PLAY MODE	Play
	Pause TV/CD		Pause
	Stop TV/CD		Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green

Original	Substituto	Original	Substituto
MUSIC REPEAT — Music / Repeat TV/CD	REPEAT TEXT — Text		
GAME RANDOM — Game / Random	C — Yellow		
STEREO PLAY MODE — Stereo / Play Mode TV/CD	D — Blue		
STEREO PLAY MODE — Stereo / Play Mode TV/CD	SHIFT + PLAY MODE — Shift + Play		
1 — 1 TV/CD	1 — 1		
2 — 2 TV/CD	2 — 2		
3 — 3 TV/CD	3 — 3		
4 — 4 TV/CD	4 — 4		
5 — 5 TV/CD	5 — 5		
6 — 6 TV/CD	6 — 6		
7 — 7 TV/CD	7 — 7		
8 — 8 TV/CD	8 — 8		
9 — 9 TV/CD	9 — 9		
11 0 — 0 TV/CD	0 — 0		
10 +10 D.TUN DIMMER — +10 / Dimmer	-/-- GUIDE — Guide		
12 CLR SLEEP — CLR / Sleep TV/C	CLEAR EXIT — Exit		
12 CLR SLEEP — CLR / Sleep TV/C	PROG SLEEP — Sleep		

Original		Substituto	
ON/STANDBY	On / Standby	Power	
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
MUTING	Muting	MUTE	Mute
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
ON/STANDBY	On / Standby Por	SHIFT + Power	Shift + Power
DISPLAY	Display Port	DISPLAY INFO	Info
CH DISC	CH + Port	CH +	Ch +
ALBUM	CH - Port	CH -	Ch -
	Up Port		Up

Original		Substituto	
PLAYLIST /CATEGORY	Left / Playlist/Categor		Left
ENTER	Enter Port	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Categor		Right
	Down Port		Down
SETUP	Setup Port	SETTINGS OPT	Options
RETURN	Return Port	RETURN BACK	Back
	I<< Port		I<<
	>>I Port		>>I
	<< Port		<<
	Play Port	PLAY MODE	Play
	>> Port		>>
	Pause / Play Reverse Port		Pause
	Stop Port		Stop
MOVIE/TV SEARCH	Movie/TV / Searc Port	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc Port	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text

Port

Original		Substituto		Original	Substituto
GAME RANDOM	Game / Random	C	Yellow		
STEREO PLAY MODE	Stereo / Play Mode Port	D	Blue		
STEREO PLAY MODE	Stereo / Play Mode Port	SHIFT + PLAY MODE	Shift + Play		
1	1 Port	1	1		
2	2 Port	2	2		
3	3 Port	3	3		
4	4 Port	4	4		
5	5 Port	5	5		
6	6 Port	6	6		
7	7 Port	7	7		
8	8 Port	8	8		
9	9 Port	9	9		
0	0 Port	0	0		
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide		
CLR SLEEP	CLR / Sleep Port	CLEAR EXIT	Exit		
CLR SLEEP	CLR / Sleep Port	PROG SLEEP	Sleep		