Original	Substituto
Mute	Mute / Dimmer
Power	Power
(↔)	Audio / Lang I/II
TV	TV/ Radio /
_/	Sound / Title
[#]→	Picture / Format
[.≡]	Text / Goto
[≡+]	Shift + Stop /
[≡♦]	Shift + Zoom /
[≡x]◷	Back / Return
[≡?][+]	Sleep / Timer
1	1
2	2
3	3
[≡i]	Info / Angle
4	4
5	5

Original	Substituto
6	6
A/B	Shift + Yellow / YouTube /
7	7
8	8
9	9
Output	AV / Input / RDS
-/--	Guide / EPG / -/--
0	0
C	Exit / Cancel / Clear
IN 123	D. Menu / Top
1-/TP Off	Fav / Marker / PC
C00	Setup / OPT /
2-/TP On	Shift + Fav / Marker / PC
Vol +	Vol +
Prog+	CH+ / Page+
Vol -	Vol -
Prog-	CH- / Page-

Original	Substituto
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
→>	Display / Media
-[<>]	Left
[<>]+	Right
♦	Zoom / Size
(*)	Menu / Home
→←	Smart / List
[II··]	OK
[II··]+	Up
[...]	Subtitle / EQ
Contrast+	>>I / Preset+
Brightness+	Shift + Right
[II··]-	Down
Prog+ Down	Shift + CH+ / Page+

Original	Substituto
Contrast-	I<< / Preset-
Brightness-	Shift + Left
Power Down	Shift + Power
Prog- Down	Shift + CH- /
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Stop	Stop / Hold
Pause	Pause / Step / Freeze

Original	Substituto
Power Down	Power
Prog+ Down	CH+ / Page+
Prog- Down	CH- / Page-
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Rec	Rec / Rec Mode
>>	>> / Tune+
Play	Play / Slow
<<	<< / Tune-

Original	Substituto

Original		Substituto	
	Power Down		Power
	Prog+ Down		CH+ / Page+
	Prog- Down		CH- / Page-
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode
	>>		>> / Tune+
	Play		Play / Slow
	<<		<< / Tune-

Original	Substituto

Original	Substituto
Power Down	Power
Prog+ Down	CH+ / Page+
Prog- Down	CH- / Page-
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Rec	Rec / Rec Mode

Original	Substituto