Mandis shop

RMT-CS200AD

Original	Substituto	Original	Substituto
Operate (AC Only)	Power		
Function	Menu		
Band	TV/R		
Play/Pause	Play		
Play	Yellow		
Pause	Pause		
>>I/Preset+	>>I		
>>/Tune+	>>		
I<</Preset-	I<<		
<</Tune-	<<		
Stop	Stop		
Vol+	Vol +		
Vol-	Vol -		

https://controleremoto.pt/pt/Sony/1062926-91480-comando-de-substituicao-para-Sony-RMT-CS200AD.html