Original		Substituto	
	Standby / On		Power
	Search	SEARCH TV/R	TV/R
	Display	DISPLAY INFO	Info
	Repeat	REPEAT TEXT	Text
	Repeat A-B	SHIFT + REPEAT TEXT	Shift + Text
	Audio	SOUND DUAL	Dual
	Subtitle	AD SUBT	Subt
	Zoom	ZOOM	Eject
	Angle	PICTURE FORMAT	Format
	Return	RETURN BACK	Back
	Title	DISC NAV LIST	List
	Clear	CLEAR EXIT	Exit
	>>I	>>I	>>I
	I <<	I <<	I <<
	DVD	HOME SMART	Smart
	Disc Menu	E-MANUAL D.MENU	D. Menu
	System Menu	TOP MENU MENU	Menu

Original		Substituto	
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
MARKER	Marker	FAV PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Substituto		Original		Substituto	
9	9	9	9				
0	0	0	0				

Original		Substituto	
STANDBY-ON	Standby / On		Power
SEARCH	Search	SEARCH TV/R	TV/R
DISPLAY	Display	DISPLAY INFO	Info
CLEAR/RESET	Clear	CLEAR EXIT	Exit
VCR	VCR	HOME SMART	Smart
VCR/TV	TV / VCR	APP MEDIA	Media
SYSTEM MENU	System Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	<<		<<
	>>		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause

Original		Substituto	
MARKER	Marker	FAV PRE-CH	Pre Ch
RECORD	Rec	REC MODE	Rec
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0