Mandis shop

JVC HR-D300

Original		Substituto	
	Power		Power
	TV PR-	CH PAGE	CH- / Page-
	PR-		Left
	TV P-		Down
	TV PR+	CH PAGE	CH+ / Page+
	PR+		Right
	TV P+		Up
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Rec	REC MODE	Rec / Rec Mode
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original	Substituto

https://controleremoto.pt/pt/JVC/1065143-95721-comando-de-substituicao-para-JVC-HR-D300.html