Mandis shop

IH6-IH8

Original		Substituto		Original		Substituto	
alm. reset	Power/alm./reset		Power				
▶II	Play	SLOW ▶	Play / Slow				
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
mute	Mute	DIMMER MUTE	Mute / Dimmer				
🔊	Vol+	+ VOL	Vol+				
🔉	Vol-	VOL −	Vol-				
presets	Preset	OPT-TOOLS SETUP	Setup / OPT /				
eq	EQ	EQ SUBTITLE	Subtitle / EQ				
radio	Radio	PROGRAM TV/RADIO	TV/Radio /				
snooze/dimmer	Snooze/dimmer	OK	OK				

https://controleremoto.pt/pt/IHOME/1065806-94709-comando-de-substituicao-para-IHOME-iH6-iH8.html