Original		Substituto	
ON POWER	Power On		Power
OFF POWER	Power Off	SHIFT +	Shift + Power
1 SPEAKERS	Speakers 1	CH PAGE +	CH+ / Page+
2 SPEAKERS	Speakers 2	CH PAGE −	CH- / Page-
Phono	PHONO	SHIFT + USB 8	Shift + 8
CD	CD	SHIFT + CD - STB 3	Shift + 3
VID 1	VID 1	SHIFT + TV 1	Shift + 1
VID 2	VID 2	SHIFT + DVD 2	Shift + 2
VID 3	VID 3	SHIFT + VIDEO 4	Shift + 4
FM	FM	SHIFT + TUNER 6	Shift + 6
AM	AM	SHIFT + AUX - HDD 7	Shift + 7
Tape Mon	TAPE MON	SHIFT + TAPE 5	Shift + 5
FM Mode	FM Mode	MEDIA DISPLAY	Display / Media
Auto Preset	Auto Preset	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3

Original		Substituto	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DIRECT	Direct	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MEMORY	Memory	PC FAV MARKER	Fav / Marker / PC
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
OK	OK	OK	OK
	Right		Right
PRESET SCAN	Preset Scan	ANGLE INFO	Info / Angle
	Down		Down

Original	Substituto	Original	Substituto
Vol+	Vol+		
Mute	Mute / Dimmer		
Tune Up	>> / Tune+		
Vol-	Vol-		
Tune Down	<< / Tune-		
Preset Down	I<< / Preset-		
Preset Up	>>I / Preset+		
Dimmer	Shift + Mute / Dimmer		
Sleep	Sleep / Timer		