Mandis shop

RM-V730U

Original		Substituto	
T ZOOM	Zoom T	CH PAGE +	CH+ / Page+
START/STOP	Star/Stop		Power
ZOOM W	Zoom W	CH PAGE −	CH- / Page-
SNAPSHOT	Snapshot	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
−	-	VOL −	Vol -
	Up		Up
+	+	VOL +	Vol +
<<	<<	TUNE-	<< / Tune-
Left	Left		Left
SET	SET	OPT-TOOLS SETUP	Setup / OPT /
SET	Play	SLOW	Play / Slow
SET	Pause	STEP-FREEZE	Pause / Step / Freeze
Right	Right		Right
>>	>>	TUNE+	>> / Tune+
I <<	I <<	PRESET-	I << / Preset-
Down	Down		Down

Original		Substituto	
>>I	>>I	PRESET+ >>I	>>I / Preset+
PLAYLIST	Playlist	MEDIA DISPLAY	Display / Media
DATE	Date	TIMER SLEEP	Sleep / Timer
INDEX	Index	LIST SMART	Smart / List

https://ordered.com/p/JVC10687-857-mando-substituto-para-JVC-RM-V730U.htm